

Welcome to the Danico Catalogue of Electrical Accessories



e are an independent family-owned company established in 1979 with three generations of experience in Architectural Ironmongery, Electrical Accessories and Bathroom Accessories. Our

showroom and head office is based in Swiss Cottage, North London. We are able to advise and supply a comprehensive range of the above products, offering you the widest possible choice of high quality, value for money products.

Our clients include discerning homeowners, architects, builders, interior designers, hotels and corporations who are building new properties or refurbishing existing homes. We can supply any product anywhere in the world.

In this 68 page Electrical Accessory catalogue most designs have been photographed actual size, to help you first select the plate design and finish, and then prepare a schedule of the individual components required from the full listing. A key to the abbreviated finish codes is shown on the contents page opposite. It has only been possible to show the majority of our standard range of products. Other items, and special finishes, are available to order. We also have the facilities to manufacture "special" items, made to client's specifications and designs.

All our electrical products comply with the applicable British Standard specification and should only be installed by a suitably qualified electrician, in accordance with the requirements of relevant legislation, and the accepted practice in the industry.

On the last two pages we show a small selection of Decorative Grilles, Jado Bathroom Accessories and Architectural Ironmongery. Separate catalogues and full information is available on request.


Our experienced and friendly staff will be delighted to welcome you to our showroom or to help and advise you on the telephone, via fax or email. We hope you find our catalogue informative and easy to use.





Rahul, Rishi, Annelise and Ashok Daryanani





First published 2003

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical or otherwise, without prior permission in writing of the copyright owners.

Published by DANICO BRASS LIMITED.

Design

MUSE Fine Art & Design Ltd, Brighton, UK

Printed by

Universal Media Services Ltd, UK

All products are offered for sale only under the terms of our Standard Conditions of Sale. Danico pursues a policy of constantly updating and reviewing the product range and the company reserves the right to alter specification or availability without notice.

Danico Brass Limited

31 - 35 Winchester Road Swiss Cottage London NW3 3NR Tel: 020 7483 4477

Fax: 020 7722 7992 e-mail: sales@danico.co.uk



FINISH	DESCRIPTION	FINISH	DESCRIPTION
ANTBR	Antique Brass	PB	Polished Brass
ANTGO	Antique Gold	PB/CP	Polished Brass & Chrome
BJP	Black Japanned	PB/UL	Polished Brass Un-Lacquered
BLACK	Black	PB/WH	Polished Brass & White
BLKNK	Black Nickel		Polished Stainless Steel
BRW	Brown	S/COL	Self Colour
CLEAR	Clear Glass or Acrylic	SAB	Satin Brass
CP	Polished Chrome	SCP	Satin Chrome Plated
	Chrome & White	SC/CP	Satin Chrome & Polished Chrome
GREY	Grey Enamel	SNP	Satin Nickel Plated
IBMA	Imitation Bronze Metal Antique	SSS	Satin Stainless Steel
	Matt Nickel (Satin Nickel)	SB/PB	Satin Brass & Polished Brass
NP	Polished Nickel Plated	WHI	White
PATIN	Patine Steel		



900.032.10 (Shown Actual Size)




900.001.10





900.021.10



900.003.10



900.023.10



900.061.10



900.015.10



900.014.10



900.031.10

900.034.10


900.092.10



900.070.10



900.037.10



900.012.10



900.091.10



900.050.10



900.040.10




Material	Small Plate	Large Plate	Interior
Die Cast Brass	96 x 96mm	156 x 96mm	Crabtree White

Rocker Trim Plate

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)					
900.001.10	I Gang Switch 2 Way	WHI	WHI	PB		
900.002.10	2 Gang Switch 2 Way	WHI	WHI	PB		
900.003.10	3 Gang Switch 2 Way	WHI	WHI	PB		
900.004.10	4 Gang Switch 2 Way	WHI	WHI	PB		
900.005.10	Spur Fused with Switch	WHI	WHI	PB		
900.006.10	Spur Fused with Switch & Cord Outlet	WHI	WHI	PB		
900.007.10	Spur Fused with Neon	WHI	WHI	PB		
900.008.10	Spur Fused with Neon & Cord Outlet	WHI	WHI	PB		
900.009.10	I Gang Switch: Intermediate	WHI	WHI	PB		

INTERCHAN	IGEABLE GRID SWITCHES (METAL RO	CKER)		
900.011.10	I Gang Switch 2 Way	PB	WHI	PB
900.012.10	2 Gang Switch 2 Way	PB	WHI	PB
900.013.10	3 Gang Switch 2 Way	PB	WHI	PB
900.014.10	4 Gang Switch 2 Way	PB	WHI	PB
900.015.10	Spur Fused with Switch	PB	WHI	PB
900.017.10	Spur Fused with Neon	PB	WHI	PB
900.019.10	I Gang Switch: Intermediate	PB	WHI	PB
900.020.10	I Gang Switch, 20amp Double-Pole	PB	WHI	PB



900.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
900.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
900.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
900.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
900.026.10	I Gang Dimmer Switch, 630 Watts 2 Way	PB
900.027.10	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	PB
900.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB



900.030.10	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	PB
900.031.10	13amp Single Socket	PB	WHI	PB
900.032.10	13amp Double Socket	PB	WHI	PB
900.033.10	2 amp Single Socket		WHI	PB
900.034.10	5 amp Single Socket		WHI	PB
900.091.10	13amp Single Socket	WHI	WHI	PB
900.092.10	13amp Double Socket	WHI	WHI	PB

900 Series: POLISHED BRASS

Code Description Rocker	Trim	Plate
000 025 10 TV O d d d d d	\ A / L II	
900.035.10 TV Outlet, Isolated	WHI	PB PB
900.035.10.NI TV Outlet, Non Isolated	WHI	PB
900.036.10 TV/FM Outlet, Isolated 900.036.10.NI TV/FM Outlet Non-Isolated	WHI	PB
900.037.10 Telecom Outlet, Master	WHI	PB
900.038.10 Telecom Outlet, Slave	WHI	PB
900.039.10 Cord Outlet, Grommet on Plate	WHI	PB
900.047.10 Twin-Telecom, Master	WHI	PB
900.048.10 Twin-Telecom, Slave	WHI	PB
700.048.10 I Win- I elecom, Slave	VV III	
		0
<u>•</u>		1
	— I	
	m II í	ا ۾ ه
		B 25
900.040.10 Cooker Switch 45amp D/P with Neon RED	WHI	PB
900.040.10.SP 45amp Double-Pole Switch with Neon RED	WHI	PB
900.041.10 Blanking Plate Single	******	PB
900.042.10 Blanking Plate Double		PB
900.046.10 Cooker Switch 45amp with 13amp Socket RED	WHI	PB
900.050.10 Shaver Socket	WHI	PB
700.000.110 Shayor Society	******	
		٦
	l₀ ∏ ₀	,
	⊔	
		J
900.061.10 I Gang Moulded Rocker Switch 2 Way WHI		PB
900.062.10 2 Gang Moulded Rocker Switch 2 Way WHI		PB
900.063.10 3 Gang Moulded Rocker Switch 2 Way WHI		PB
900.064.10 4 Gang Moulded Rocker Switch 2 Way WHI		PB
900.065.10 Spur Fused with Switch WHI		PB
900.069.10 I Gang Moulded Rocker Switch: Intermediate WH	I	PB
6		
900.070.10 Fan Isolator Switch, 3 Pole WHI		PB
900.071.10 I Gang Architrave Switch, 92x45mm WHI	WHI	PB
900.081.10 I Gang Architrave Switch, 92x45mm PB	WHI	PB
	_	
	a	
	°	

900.099.10.01 | Gang Speaker Outlet

I Gang Satellite Socket

TV + FM + Satellite Outlet

TV + Satellite Socket

900.245.10.01 | Gang Data Socket, RJ45(Cat5)

900.245.10.02 2 Gang Data Socket, RJ45(Cat5)

900.234.10

900.235.10

900.236.10

Also Available:

WHI

WHI

WHI

PB

РΒ

PB

PB

РΒ



901.013.10 (Shown Actual Size)



901.071.10

901.245.10.02

901.033.10



901.036.10.NI


901.063.10

Material	Small Plate	Large Plate	Interior
Die Cast Brass	86 x 86mm	146 x 86mm	Crabtree White

Rocker Trim Plate Description Code 0 FUSE 0

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)					
901.001.10	I Gang Switch 2 Way	WHI	WHI	PB		
901.002.10	2 Gang Switch 2 Way	WHI	WHI	PB		
901.003.10	3 Gang Switch 2 Way	WHI	WHI	PB		
901.004.10	4 Gang Switch 2 Way	WHI	WHI	PB		
901.005.10	Spur Fused with Switch	WHI	WHI	PB		
901.006.10	Spur Fused with Switch & Cord Outlet	WHI	WHI	PB		
901.007.10	Spur Fused with Neon	WHI	WHI	PB		
901.008.10	Spur Fused with Neon & Cord Outlet	WHI	WHI	PB		
901.009.10	I Gang Switch: Intermediate	WHI	WHI	PB		
'						

INTERCHAN	IGEABLE GRID SWITCHES (METAL RO	OCKER)		
901.011.10	I Gang Switch 2 Way	PB	WHI	PB
901.012.10	2 Gang Switch 2 Way	PB	WHI	PB
901.013.10	3 Gang Switch 2 Way	PB	WHI	PB
901.014.10	4 Gang Switch 2 Way	PB	WHI	PB
901.015.10	Spur Fused with Switch	PB	WHI	PB
901.017.10	Spur Fused with Neon	PB	WHI	PB
901.019.10	I Gang Switch: Intermediate	PB	WHI	PB
901.020.10	I Gang Switch, 20amp Double-Pole	PB	WHI	PB
	-			



901.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
901.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
901.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
901.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
901.026.10	I Gang Dimmer Switch, 630 Watts 2 Way	PB
901.027.10	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	PB
901.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB

⊗ F S S		·&•	


901.030.10	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	PB
901.031.10	13amp Single Socket	PB	WHI	PB
901.032.10	13amp Double Socket	PB	WHI	PB
901.033.10	2 amp Single Socket		WHI	PB
901.034.10	5 amp Single Socket		WHI	PB
901.091.10	13amp Single Socket	WHI	WHI	PB
901.092.10	13amp Double Socket	WHI	WHI	PB

901 Series: POLISHED BRASS

Code Description

Rocker Trim Plate


901.035.10 TV Outlet, Isolated	WHI	PB
901.035.10.NI TV Outlet, Non Isolated	WHI	PB
901.036.10 TV/FM Outlet, Isolated	WHI	PB
901.036.10.NI TV/FM Outlet Non-Isolated	WHI	PB
901.037.10 Telecom Outlet, Master	WHI	PB
901.038.10 Telecom Outlet, Slave	WHI	PB
901.039.10 Cord Outlet, Grommet on Plate	WHI	PB
901.047.10 Twin-Telecom, Master	WHI	PB
901.048.10 Twin-Telecom, Slave	WHI	PB




901.040.10	Cooker Switch 45amp D/P with Neon	RED	WHI	PB
901.040.10.SP	45amp Double-Pole Switch with Neon	RED	WHI	PB
901.041.10	Blanking Plate Single			PB
901.042.10	Blanking Plate Double			PB
901.046.10	Cooker Switch 45amp with 13amp Socket	RED	WHI	PB
901.050.10	Shaver Socket		WHI	PB



901.061.10	I Gang Moulded Rocker Switch 2 Way	WHI	PB
901.062.10	2 Gang Moulded Rocker Switch 2 Way	WHI	PB
901.063.10	3 Gang Moulded Rocker Switch 2 Way	WHI	PB
901.064.10	4 Gang Moulded Rocker Switch 2 Way	WHI	PB
901.065.10	Spur Fused with Switch	WHI	PB
901.069.10	I Gang Moulded Rocker Switch: Interme	diate WHI	PB



901.070.10	Fan Isolator Switch, 3 Pole	WHI		PB
901.071.10	I Gang Architrave Switch, 86x35mm	WHI	WHI	PB
901.072.10	2 Gang Architrave Switch, 146x35mm	WHI	WHI	PB
901.081.10	I Gang Architrave Switch, 86x35mm	PB	WHI	PB
901.082.10	2 Gang Architrave Switch, 146x35mm	PB	WHI	PB



901.099.10.01	I Gang Speaker Outlet	WHI	PB
901.234.10	I Gang Satellite Socket		PB
901.235.10	TV + Satellite Socket		PB
901.236.10	TV + FM + Satellite Outlet		PB
901.245.10.01	I Gang Data Socket, RJ45(Cat5)	WHI	PB
901.245.10.02	2 Gang Data Socket, RJ45(Cat5)	WHI	PB

Also Available:






901.012.20 (Shown Actual Size)

901.001.20

901.022.20

901.091.20



901.004.20




901.024.20



901.092.20



901.040.20.SP



901.046.20



901.031.20 (Shown Actual Size)



901.013.20



901.081.20



901.061.20



0

901.065.20



901.032.20



901.033.20



901.050.20




Material	Small Plate	Large Plate	Interior
Die Cast Brass	86 x 86mm	146 x 86mm	Crabtree White

Rocker Trim Plate Code Description

INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)				
901.001.20	I Gang Switch 2 Way	WHI	WHI	CP
901.002.20	2 Gang Switch 2 Way	WHI	WHI	CP
901.003.20	3 Gang Switch 2 Way	WHI	WHI	CP
901.004.20	4 Gang Switch 2 Way	WHI	WHI	СР
901.005.20	Spur Fused with Switch	WHI	WHI	СР
901.006.20	Spur Fused with Switch & Cord Outlet	WHI	WHI	CP
901.007.20	Spur Fused with Neon	WHI	WHI	CP
901.008.20	Spur Fused with Neon & Cord Outlet	WHI	WHI	СР
901.009.20	I Gang Switch: Intermediate	WHI	WHI	СР

INTERCHAN	IGEABLE GRID SWITCHES (METAL RO	OCKER)		
901.011.20	I Gang Switch 2 Way	CP	WHI	CP
901.012.20	2 Gang Switch 2 Way	CP	WHI	СР
901.013.20	3 Gang Switch 2 Way	CP	WHI	СР
901.014.20	4 Gang Switch 2 Way	CP	WHI	СР
901.015.20	Spur Fused with Switch	CP	WHI	CP
901.017.20	Spur Fused with Neon	CP	WHI	CP
901.019.20	I Gang Switch: Intermediate	СР	WHI	СР
901.020.20	I Gang Switch, 20amp Double-Pole	CP	WHI	СР



901.021.20	I Gang Dimmer Switch 400 Watts 2 Way	СР
901.022.20	2 Gang Dimmer Switch 400 Watts 2 Way	CP
901.023.20	3 Gang Dimmer Switch 400 Watts 2 Way	CP
901.024.20	4 Gang Dimmer Switch 400 Watts 2 Way	CP
901.026.20	I Gang Dimmer Switch, 630 Watts 2 Way	CP
901.027.20	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	СР
901.028.20	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	CP

0 F 0		·&•	

901.030.20	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	СР
901.031.20	13amp Single Socket	CP	WHI	СР
901.032.20	13amp Double Socket	CP	WHI	СР
901.033.20	2 amp Single Socket		WHI	СР
901.034.20	5 amp Single Socket		WHI	СР
901.091.20	13amp Single Socket	WHI	WHI	СР
901.092.20	13amp Double Socket	WHI	WHI	СР

901 Series: POLISHED CHROME

Rocker Trim Plate


Д Д 15V 25V В

CP


Code Description

901.035.20 TV Outlet, Isolated	WHI	CP
901.035.20.NI TV Outlet, Non Isolated	WHI	СР
901.036.20 TV/FM Outlet, Isolated	WHI	СР
901.036.20.NI TV/FM Outlet Non-Isolated	WHI	СР
901.037.20 Telecom Outlet, Master	WHI	СР
901.038.20 Telecom Outlet, Slave	WHI	CP
901.039.20 Cord Outlet, Grommet on Plate	WHI	CP
901.047.20 Twin-Telecom, Master	WHI	СР
901.048.20 Twin-Telecom, Slave	WHI	СР
•		0

901.040.20	Cooker Switch 45amp D/P with Neon	RED	WHI	CP
901.040.20.SP	45amp Double-Pole Switch with Neon	RED	WHI	CP
901.041.20	Blanking Plate Single			CP
901.042.20	Blanking Plate Double			CP
901.046.20	Cooker Switch 45amp with 13amp Socket	RED	WHI	CP
901.050.20	Shaver Socket		WHI	CP




I Gang Moulded Rocker Switch: Intermediate WHI



901.069.20


9	901.070.20	Fan Isolator Switch, 3 Pole	WHI		CP
(901.071.20	I Gang Architrave Switch, 86x35mm	WHI	WHI	СР
(901.072.20	2 Gang Architrave Switch, 146x35mm	WHI	WHI	СР
(901.081.20	I Gang Architrave Switch, 86x35mm	CP	WHI	СР
(901.082.20	2 Gang Architrave Switch, 146x35mm	CP	WHI	CP




901.099.20.01	I Gang Speaker Outlet	WHI	CP
901.234.20	I Gang Satellite Socket		CP
901.235.20	TV + Satellite Socket		CP
901.236.20	TV + FM + Satellite Outlet		CP
901.245.20.01	I Gang Data Socket, RJ45(Cat5)	WHI	CP
901.245.20.02	2 Gang Data Socket, RJ45(Cat5)	WHI	CP

Also Available:





901.023.21 (Shown Actual Size)








901.011.21



901.021.21











901.027.21






Material	Material Small Plate		Interior
Die Cast Brass	86 x 86mm	146 x 86mm	Crabtree White

Rocker Trim Plate Description 0 FUSE 0

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)				
901.001.21	I Gang Switch 2 Way	WHI	WHI	SCP	
901.002.21	2 Gang Switch 2 Way	WHI	WHI	SCP	
901.003.21	3 Gang Switch 2 Way	WHI	WHI	SCP	
901.004.21	4 Gang Switch 2 Way	WHI	WHI	SCP	
901.005.21	Spur Fused with Switch	WHI	WHI	SCP	
901.006.21	Spur Fused with Switch & Cord Outlet	WHI	WHI	SCP	
901.007.21	Spur Fused with Neon	WHI	WHI	SCP	
901.008.21	Spur Fused with Neon & Cord Outlet	WHI	WHI	SCP	
901.009.21	I Gang Switch: Intermediate	WHI	WHI	SCP	

INTERCHAN	IGEABLE GRID SWITCHES (METAL RO	CKER)		
901.011.21	I Gang Switch 2 Way	SCP	WHI	SCP
901.012.21	2 Gang Switch 2 Way	SCP	WHI	SCP
901.013.21	3 Gang Switch 2 Way	SCP	WHI	SCP
901.014.21	4 Gang Switch 2 Way	SCP	WHI	SCP
901.015.21	Spur Fused with Switch	SCP	WHI	SCP
901.017.21	Spur Fused with Neon	SCP	WHI	SCP
901.019.21	I Gang Switch: Intermediate	SCP	WHI	SCP
901.020.21	I Gang Switch, 20amp Double-Pole	SCP	WHI	SCP
	•			



901.021.21	I Gang Dimmer Switch 400 Watts 2 Way	SCP
901.022.21	2 Gang Dimmer Switch 400 Watts 2 Way	SCP
901.023.21	3 Gang Dimmer Switch 400 Watts 2 Way	SCP
901.024.21	4 Gang Dimmer Switch 400 Watts 2 Way	SCP
901.026.21	I Gang Dimmer Switch, 630 Watts 2 Way	SCP
901.027.21	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	SCP
901.028.21	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SCP

0 FU 0		


901.030.21	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SCP
901.031.21	13amp Single Socket	SCP	WHI	SCP
901.032.21	13amp Double Socket	SCP	WHI	SCP
901.033.21	2 amp Single Socket		WHI	SCP
901.034.21	5 amp Single Socket		WHI	SCP
901.091.21	13amp Single Socket	WHI	WHI	SCP
901.092.21	13amp Double Socket	WHI	WHI	SCP

901 Series: SATIN CHROME


Rocker Trim Plate

Code Description


901.035.21 TV Outlet, Isolated	WHI	SCP
901.035.21.NI TV Outlet, Non Isolated	WHI	SCP
901.036.21 TV/FM Outlet, Isolated	WHI	SCP
901.036.21.NI TV/FM Outlet Non-Isolated	WHI	SCP
901.037.21 Telecom Outlet, Master	WHI	SCP
901.038.21 Telecom Outlet, Slave	WHI	SCP
901.039.21 Cord Outlet, Grommet on Plate	WHI	SCP
901.047.21 Twin-Telecom, Master	WHI	SCP
901.048.21 Twin-Telecom, Slave	WHI	SCP




901.040.21	Cooker Switch 45amp D/P with Neon	RED	WHI	SCP
901.040.21.SP	45amp Double-Pole Switch with Neon	RED	WHI	SCP
901.041.21	Blanking Plate Single			SCP
901.042.21	Blanking Plate Double			SCP
901.046.21	Cooker Switch 45amp with 13amp Socket	RED	WHI	SCP
901.050.21	Shaver Socket		WHI	SCP



901.061.21	I Gang Moulded Rocker Switch 2 Way	WHI	SCP
901.062.21	2 Gang Moulded Rocker Switch 2 Way	WHI	SCP
901.063.21	3 Gang Moulded Rocker Switch 2 Way	WHI	SCP
901.064.21	4 Gang Moulded Rocker Switch 2 Way	WHI	SCP
901.065.21	Spur Fused with Switch	WHI	SCP
901.069.21	I Gang Moulded Rocker Switch: Intermed	diate WHI	SCP



901.070.21	Fan Isolator Switch, 3 Pole	WHI	WHI	SCP
901.071.21	I Gang Architrave Switch, 86x35mm	WHI	WHI	SCP
901.072.21	2 Gang Architrave Switch, 146x35mm	WHI	WHI	SCP
901.081.21	I Gang Architrave Switch, 86x35mm	SCP	WHI	SCP
901.082.21	2 Gang Architrave Switch, 146x35mm	SCP	WHI	SCP



901.099.21.01	I Gang Speaker Outlet	WHI	SCP
901.234.21	I Gang Satellite Socket		SCP
901.235.21	TV + Satellite Socket		SCP
901.236.21	TV + FM + Satellite Outlet		SCP
901.245.21.01	I Gang Data Socket, RJ45(Cat5)	WHI	SCP
901.245.21.02	2 Gang Data Socket, RJ45(Cat5)	WHI	SCP

Also Available:






902.011.10 (Shown Actual Size)



902.033.10 (Shown Actual Size)



902.002.10



902.004.10



902.005.10



902.013.10



902.022.10



902.024.10




902.031.10



902.032.10











902.063.10



902.245.10.02




902.050.10

Material	Small Plate	Large Plate	Interior
Die Cast Brass	86 x 86mm	148 x 86mm	Crabtree White


Rocker Trim Plate Code Description

INTERCHAN	IGEABLE GRID SWITCHES (PLASTIC RO	CKER)		
902.001.10	I Gang Switch 2 Way	WHI	WHI	PB
902.002.10	2 Gang Switch 2 Way	WHI	WHI	PB
902.003.10	3 Gang Switch 2 Way	WHI	WHI	PB
902.004.10	4 Gang Switch 2 Way	WHI	WHI	PB
902.005.10	Spur Fused with Switch	WHI	WHI	PB
902.006.10	Spur Fused with Switch & Cord Outlet	WHI	WHI	PB
902.007.10	Spur Fused with Neon	WHI	WHI	PB
902.008.10	Spur Fused with Neon & Cord Outlet	WHI	WHI	PB
902.009.10	I Gang Switch: Intermediate	WHI	WHI	PB

INTERCHAN	IGEABLE GRID SWITCHES (METAL RO	OCKER)		
902.011.10	I Gang Switch 2 Way	PB	WHI	PB
902.012.10	2 Gang Switch 2 Way	PB	WHI	PB
902.013.10	3 Gang Switch 2 Way	PB	WHI	PB
902.014.10	4 Gang Switch 2 Way	PB	WHI	PB
902.015.10	Spur Fused with Switch	PB	WHI	PB
902.017.10	Spur Fused with Neon	PB	WHI	PB
902.019.10	I Gang Switch: Intermediate	PB	WHI	PB
902.020.10	I Gang Switch, 20amp Double-Pole	PB	WHI	PB



902.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
902.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
902.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
902.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
902.026.10	I Gang Dimmer Switch, 630 Watts 2 Way	PB
902.027.10	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	PB
902.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB
	-	




902.030.10	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	PB
902.031.10	13amp Single Socket	PB	WHI	PB
902.032.10	13amp Double Socket	PB	WHI	PB
902.033.10	2 amp Single Socket		WHI	PB
902.034.10	5 amp Single Socket		WHI	PB
902.091.10	13amp Single Socket	WHI	WHI	SCP
902.092.10	13amp Double Socket	WHI	WHI	SCP

902 Series: POLISHED BRASS

Code Description Rocker	Trim	Plate
902.035.10 TV Outlet, Isolated	WHI	PB
902.035.10.NI TV Outlet, Non Isolated	WHI	PB
902.036.10 TV/FM Outlet, Isolated	WHI	PB
902.036.10.NI TV/FM Outlet Non-Isolated	WHI	PB
902.037.10 Telecom Outlet, Master	WHI	PB
902.038.10 Telecom Outlet, Slave	WHI	PB
902.039.10 Cord Outlet, Grommet on Plate	WHI	PB
902.047.10 Twin-Telecom, Master	WHI	PB
902.048.10 Twin-Telecom, Slave	WHI	PB
		Ø
902.040.10 Cooker Switch 45amp D/P with Neon RED	WHI	PB
902.040.10.SP 45amp Double-Pole Switch with Neon RED	WHI	PB
902.041.10 Blanking Plate Single		PB PB
902.042.10 Blanking Plate Double 902.046.10 Cooker Switch 45amp with 13amp Socket RED	WHI	PB
902.050.10 Shaver Socket RED	WHI	PB
702.030.10 Shaver Socket	V V I	ГВ
	 []	ø
902.061.10 I Gang Moulded Rocker Switch 2 Way WHI		PB
902.062.10 2 Gang Moulded Rocker Switch 2 Way WHI		PB
902.063.10 3 Gang Moulded Rocker Switch 2 Way WHI		PB
902.064.10 4 Gang Moulded Rocker Switch 2 Way WHI		PB
902.065.10 Spur Fused with Switch WHI		PB
902.069.10 I Gang Moulded Rocker Switch: Intermediate WH	I	PB

0 0		
-----	--	--

902.070.10	Fan Isolator Switch, 3 Pole		WHI		PB
902.071.10	I Gang Architrave Switch,	92x45mm	WHI	WHI	PB
902.081.10	I Gang Architrave Switch,	92x45mm	PB	WHI	PB



902.099.10.01	I Gang Speaker Outlet	WHI	PB
902.234.10	I Gang Satellite Socket		PB
902.235.10	TV + Satellite Socket		PB
902.236.10	TV + FM + Satellite Outlet		PB
902.245.10.01	I Gang Data Socket, RJ45(Cat5)	WHI	PB
902.245.10.02	2 Gang Data Socket, RJ45(Cat5)	WHI	PB

Also Available:



903.053.10 (Shown Actual Size)



903.001.10



903.013.10



903.012.10



903.015.10



903.021.10



903.023.10





903.032.10



903.091.10



903.040.10



903.051.10



903.035.10



903.034.10



903.235.10



903.037.10



903.245.10.01



903.050.10



Material	Small Plate	Large Plate	Interior
Die Cast Brass	94 x 94mm	156 x 94mm	Wandsworth

Rocker Trim Plate Code Description I Gang Switch 2 Way 903.001.10 BLK BLK PB 903.002.10 2 Gang Switch 2 Way **BLK BLK** PB РВ 903.003.10 3 Gang Switch 2 Way **BLK BLK** 903.004.10 4 Gang Switch 2 Way BLK BLK РВ 903.005.10 Spur Fused with Switch BLK BLK PB 903.009.10 I Gang Switch: Intermediate BLK BLK PB 903.011.10 I Gang Switch 2 Way PB BLK PB 903.012.10 2 Gang Switch 2 Way **BLK** PB 903.013.10 3 Gang Switch 2 Way PB BLK PB 903.014.10 PB 4 Gang Switch 2 Way PB BLK

PB

BLK


BLK

BLK

BLK

BLK

BLK



I Gang Switch: Intermediate

Spur Fused with Switch

Spur Fused with Neon

Spur Fused with Switch & Cord Outlet

Spur Fused with Neon & Cord Outlet

I Gang Switch, 20amp Double-Pole

903.015.10

903.016.10


903.017.10

903.018.10

903.019.10

903.020.10

903.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
903.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
903.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
903.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
903.026.10	I Gang Dimmer Switch 630 Watts 2 Way	PB
903.027.10	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	PB
903.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB



903.030.10	13amp Fuse-Only on 1 Gang Plate	BLK	BLK	PB
903.031.10	13amp Single Socket	PB	BLK	PB
903.091.10	13amp Single Socket	BLK	BLK	PB
903.032.10	13amp Double Socket	PB	BLK	PB
903.092.10	13amp Double Socket	BLK	BLK	PB
903.033.10	2 amp Single Socket		BLK	PB
903.034.10	5 amp Single Socket		BLK	PB



903.035.10	TV Outlet, Isolated	BLK	PB
903.035.10.NI	TV Outlet, Non Isolated		PB
903.036.10	TV/FM Outlet, Isolated	BLK	PB
903.036.10.NI	TV/FM Outlet Non-Isolated		PB
903.037.10	Telecom Outlet, Master	BLK	PB
903.038.10	Telecom Outlet, Slave	BLK	PB
903.039.10	Cord Outlet, Grommet on Plate	BLK	PB
903.047.10	Twin-Telecom, Master	BLK	PB
903.048.10	Twin-Telecom, Slave	BLK	PB

903 Series: POLISHED BRASS

Code Description R	ocker	Trim	Plate
		_	
			Ø
903.040.10 Cooker Switch 45amp D/P with Neon	BRW	BRW	PB
903.040.10.SP 45amp Double-Pole Switch with Neon	RED	BLK	PB
903.041.10 Blanking Plate Single			PB
903.042.10 Blanking Plate Double			PB
903.046.10 Cooker Switch 45amp with I 3amp Socket		BRW	PB
903.050.10 Shaver Socket		BLK	PB
9 9		9	
903.051.10 I Gang Dolly Switch 2 Way	PB		PB
903.052.10 2 Gang Dolly Switch 2 Way	PB		PB
903.053.10 3 Gang Dolly Switch 2 Way	PB		PB
903.054.10 4 Gang Dolly Switch 2 Way	PB		PB
903.059.10 I Gang Dolly Switch: Intermediate	PB		PB
703.037.10 I Gaing Dony Switch. Intermediate	- 15		
	ø ⊙ @) 0	
903.070.10 Fan Isolator Switch, 3 Pole	BLK		PB
903.098.10.01 I Gang Bell Switch, Push-to-Make	PB		PB
903.099.10.01 Gang Speaker Outlet		BLK	PB
903.234.10 I Gang Satellite Socket			PB
903.235.10 TV + Satellite Socket			PB
903.236.10 TV + FM + Satellite Outlet			PB
903.243.10.01 Gang Data Socket, RJ11		BLK	PB
903.244.10.01 Gang Data Socket, RJ12		BLK	PB
903.245.10.01 Gang Data Socket, RJ45(Cat5)		BLK	PB
903.245.10.02 2 Gang Data Socket, RJ45(Cat5)		BLK	PB
		בריל -	

Also Available:



903.032.20 (Shown Actual Size)



903.011.20



903.014.20



903.053.20



903.051.20



903.012.20



903.027.20



903.024.20



903.022.20



903.040.20



903.017.20



903.035.20



903.031.20



903.037.20



903.034.20



903.098.20.01




903.050.20




Material	Small Plate	Large Plate	Interior
Die Cast Brass	94 x 94mm	156 x 94mm	Wandsworth

Rocker Trim Plate Code Description 903 011 20 I Gang Switch 2 Way WHI СР


903.011.20	I Gang Switch 2 Way	CP	WHI	CP
903.012.20	2 Gang Switch 2 Way	CP	WHI	СР
903.013.20	3 Gang Switch 2 Way	CP	WHI	CP
903.014.20	4 Gang Switch 2 Way	CP	WHI	CP
903.015.20	Spur Fused with Switch	CP	WHI	CP
903.016.20	Spur Fused with Switch & Cord Outlet	CP	WHI	CP
903.017.20	Spur Fused with Neon	CP	WHI	CP
903.018.20	Spur Fused with Neon & Cord Outlet	CP	WHI	CP
903.019.20	I Gang Switch: Intermediate	CP	WHI	CP
903.020.20	I Gang Switch, 20amp Double-Pole	CP	WHI	CP
•				



903.021.20	I Gang Dimmer Switch 400 Watts 2 Way	CP
903.022.20	2 Gang Dimmer Switch 400 Watts 2 Way	CP
903.023.20	3 Gang Dimmer Switch 400 Watts 2 Way	CP
903.024.20	4 Gang Dimmer Switch 400 Watts 2 Way	CP
903.026.20	I Gang Dimmer Switch 630 Watts 2 Way	CP
903.027.20	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	CP
903.028.20	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	CP



903.030.20	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	CP
903.031.20	13amp Single Socket	CP	WHI	CP
903.032.20	13amp Double Socket	CP	WHI	CP
903.033.20	2 amp Single Socket		WHI	CP
903.034.20	5 amp Single Socket		WHI	CP



903.035.20	TV Outlet, Isolated	WHI	СР
903.035.20.NI	TV Outlet, Non Isolated		CP
903.036.20	TV/FM Outlet, Isolated	WHI	СР
903.036.20.NI	TV/FM Outlet Non-Isolated		CP
903.037.20	Telecom Outlet, Master	WHI	СР
903.038.20	Telecom Outlet, Slave	WHI	CP
903.039.20	Cord Outlet, Grommet on Plate	WHI	CP
903.047.20	Twin-Telecom, Master	WHI	СР
903.048.20	Twin-Telecom, Slave	WHI	CP


903 Series: POLISHED CHROME

Code	Description	Rocker	Trim	Plate
				°
				0 0 0
903.040.20	Cooker Switch 45amp D/P with N	leon WHI	WHI	СР
903.040.20.			WHI	СР
903.041.20	Blanking Plate Single			CP
903.042.20	Blanking Plate Double			CF
903.046.20	Cooker Switch 45amp with I 3amp	Socket	WHI	CP
903.050.20	Shaver Socket		WHI	CP
ଜୃ	ାଡ଼ଡ଼ା ଡ଼ଡ଼ଡ଼ା ଡ଼ଡ଼	ନୃତ୍ତ 📙	ଡ଼	
003 051 30	I Gang Dolly Switch 2 Way	СР		CF
903.051.20 903.052.20	2 Gang Dolly Switch 2 Way	CP CP		CF
903.053.20	3 Gang Dolly Switch 2 Way	CP CP		CF
903.054.20	4 Gang Dolly Switch 2 Way	CP CP		CF
903.059.20	I Gang Dolly Switch: Intermediate			CF
703.037.20	T dang Dony Switch. Intermediate	<u> </u>		
			\neg	
المصما		o o « « o e	اه	
االاسالة			7	
903.070.20	Fan Isolator Switch, 3 Pole	WHI		CF
903.098.20.	01 I Gang Bell Switch, Push-to-Make	СР		CF
903.099.20.	01 I Gang Speaker Outlet		WHI	CF
903.234.20	I Gang Satellite Socket			CF
903.235.20	TV + Satellite Socket			CF
903.236.20	TV + FM + Satellite Outlet			CF
$\overline{}$				
903.243.20.			WHI	
903.244.20.	01 Gang Data Socket, RJ12		WHI	CP
	OI I Gang Data Socket, RJI2 OI I Gang Data Socket, RJ45(Cat5)			CP CP CP

Also Available:



903.023.21 (Shown Actual Size)
























Material	Small Plate	Large Plate	Interior
Die Cast Brass	94 x 94mm	156 x 94mm	Wandsworth

Rocker Trim Plate Code Description 903.011.21 I Gang Switch 2 Way SCP WHI SCP 903.012.21 SCP 2 Gang Switch 2 Way SCP WHI SCP WHI SCP 903.013.21 3 Gang Switch 2 Way 903.014.21 4 Gang Switch 2 Way SCP WHI SCP 903.015.21 Spur Fused with Switch SCP WHI SCP Spur Fused with Switch & Cord Outlet SCP 903.016.21 SCP WHI

SCP

SCP

SCP

SCP

SCP

SCP

SCP


SCP

WHI

WHI

WHI

 WHI



Spur Fused with Neon & Cord Outlet

I Gang Switch, 20amp Double-Pole

Spur Fused with Neon

I Gang Switch: Intermediate


903.017.21

903.018.21

903.019.21

903.020.21

903.021.21	I Gang Dimmer Switch 400 Watts 2 Way	SCP
903.022.21	2 Gang Dimmer Switch 400 Watts 2 Way	SCP
903.023.21	3 Gang Dimmer Switch 400 Watts 2 Way	SCP
903.024.21	4 Gang Dimmer Switch 400 Watts 2 Way	SCP
903.026.21	I Gang Dimmer Switch 630 Watts 2 Way	SCP
903.027.21	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	SCP
903.028.21	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SCP



903.030.21	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SCP
903.031.21	13amp Single Socket	SCP	WHI	SCP
903.032.21	13amp Double Socket	SCP	WHI	SCP
903.033.21	2 amp Single Socket		WHI	SCP
903.034.21	5 amp Single Socket		WHI	SCP



903.035.21	TV Outlet, Isolated	WHI	SCP
903.035.21.NI	TV Outlet, Non Isolated		SCP
903.036.21	TV/FM Outlet, Isolated	WHI	SCP
903.036.21.NI	TV/FM Outlet Non-Isolated		SCP
903.037.21	Telecom Outlet, Master	WHI	SCP
903.038.21	Telecom Outlet, Slave	WHI	SCP
903.039.21	Cord Outlet, Grommet on Plate	WHI	SCP
903.047.21	Twin-Telecom, Master	WHI	SCP
903.048.21	Twin-Telecom, Slave	WHI	SCP

903 Series: SATIN CHROME

903.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCF 903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.041.21 Blanking Plate Single SCF 903.042.21 Blanking Plate Double SCF 903.042.21 Blanking Plate Double SCF 903.050.21 Cooker Switch 45amp with I 3amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 I Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 I Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch Push-to-Make SCP SCF 903.099.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.234.21 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJI1 WHI SCF 903.244.21.01 I Gang Data Socket, RJI2 WHI SCF 903.245.21.01 I Gang Data Socket, RJI55 WHI SCF 903.245.21.01	Code	Description	Rocker	Trim	Plate
903.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCF 903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.040.21.SI Blanking Plate Single SCP 903.042.21 Blanking Plate Double SCF 903.046.21 Cooker Switch 45amp with 13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 4 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Bell Switch, Push-to-Make SCP SCF 903.059.21 I Gang Speaker Outlet WHI SCF 903.099.21.01 I Gang Speaker Outlet SCP SCF 903.234.21 I Gang Satellite Socket SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5)					
903.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCF 903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.040.21.SI Blanking Plate Single SCP 903.042.21 Blanking Plate Double SCF 903.046.21 Cooker Switch 45amp with 13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 4 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Bell Switch, Push-to-Make SCP SCF 903.059.21 I Gang Speaker Outlet WHI SCF 903.099.21.01 I Gang Speaker Outlet SCP SCF 903.234.21 I Gang Satellite Socket SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5)	0				0
903.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCF 903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.040.21.SI Blanking Plate Single SCP 903.042.21 Blanking Plate Double SCF 903.046.21 Cooker Switch 45amp with 13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 4 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Bell Switch, Push-to-Make SCP SCF 903.059.21 I Gang Speaker Outlet WHI SCF 903.099.21.01 I Gang Speaker Outlet SCP SCF 903.234.21 I Gang Satellite Socket SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5)			St 42		
903.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCF 903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.040.21.SI Blanking Plate Single SCP 903.042.21 Blanking Plate Double SCF 903.046.21 Cooker Switch 45amp with 13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 4 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Bell Switch, Push-to-Make SCP SCF 903.059.21 I Gang Speaker Outlet WHI SCF 903.099.21.01 I Gang Speaker Outlet SCP SCF 903.234.21 I Gang Satellite Socket SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5)					
903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.041.21 Blanking Plate Single SCF 903.041.21 Blanking Plate Double SCF 903.042.21 Blanking Plate Double SCF 903.046.21 Cooker Switch 45amp with 13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 I Gang Dolly Switch 2 Way SCP SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 4 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Bell Switch, Push-to-Make SCP SCF 903.098.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Speaker Outlet SCF 903.234.21 I Gang Statellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF				o" °	D 255V
903.040.21.SP 45amp Double-Pole Switch with Neon RED WHI SCF 903.041.21 Blanking Plate Single SCF 903.041.21 Blanking Plate Double SCF 903.042.21 Blanking Plate Double SCF 903.046.21 Cooker Switch 45amp with 13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 I Gang Dolly Switch 2 Way SCP SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.053.21 4 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Bell Switch, Push-to-Make SCP SCF 903.098.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Speaker Outlet SCF 903.234.21 I Gang Statellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF					0
903.041.21 Blanking Plate Single 903.042.21 Blanking Plate Double 903.046.21 Cooker Switch 45amp with 13amp Socket 903.050.21 Shaver Socket 903.050.21 Shaver Socket 903.051.21 I Gang Dolly Switch 2 Way 903.052.21 2 Gang Dolly Switch 2 Way 903.052.21 2 Gang Dolly Switch 2 Way 903.053.21 3 Gang Dolly Switch 2 Way 903.053.21 3 Gang Dolly Switch 2 Way 903.054.21 4 Gang Dolly Switch 2 Way 903.059.21 I Gang Dolly Switch: Intermediate 903.059.21 I Gang Bell Switch, 3 Pole 903.092.1.01 I Gang Bell Switch, Push-to-Make 903.092.1.01 I Gang Speaker Outlet 903.234.21 I Gang Satellite Socket 903.235.21 TV + Satellite Socket 903.235.21 TV + Satellite Socket 903.236.21 TV + FM + Satellite Outlet 903.243.21.01 I Gang Data Socket, RJ11 903.244.21.01 I Gang Data Socket, RJ12 903.245.21.01 I Gang Data Socket, RJ2 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF	903.040.21	Cooker Switch 45amp D/P with Neo	n WHI	WHI	SCP
903.042.21 Blanking Plate Double 903.046.21 Cooker Switch 45amp with 13amp Socket 903.050.21 Shaver Socket 903.050.21 Shaver Socket 903.051.21 I Gang Dolly Switch 2 Way 903.051.21 I Gang Dolly Switch 2 Way 903.052.21 2 Gang Dolly Switch 2 Way 903.052.21 3 Gang Dolly Switch 2 Way 903.053.21 3 Gang Dolly Switch 2 Way 903.059.21 I Gang Dolly Switch 2 Way 903.059.21 I Gang Dolly Switch: Intermediate 903.059.21 I Gang Bell Switch: Intermediate 903.098.21.01 I Gang Bell Switch, Push-to-Make 903.099.21.01 I Gang Speaker Outlet 903.234.21 I Gang Satellite Socket 903.235.21 TV + Satellite Socket 903.235.21 TV + Satellite Outlet 903.243.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF	903.040.21		n RED	WHI	SCP
903.046.21 Cooker Switch 45amp with13amp Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 Shaver Socket WHI SCF 903.050.21 I Gang Dolly Switch 2 Way SCP SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.235.21 TV + Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.243.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF					SCP
903.050.21 Shaver Socket WHI SCF 903.050.21 I Gang Dolly Switch 2 Way SCP SCF 903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.099.21.01 I Gang Satellite Socket SCF 903.234.21 I Gang Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF			1	\ A // II	
903.051.21			ocket		
903.051.21	703.030.21	Snaver Socket		VV	3CF
903.051.21					
903.051.21			രെ	രി	
903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.070.21 Fan Isolator Switch, 3 Pole WHI SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF	8		v v	8	
903.052.21 2 Gang Dolly Switch 2 Way SCP SCF 903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.070.21 Fan Isolator Switch, 3 Pole WHI SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF					
903.053.21 3 Gang Dolly Switch 2 Way SCP SCF 903.054.21 4 Gang Dolly Switch 2 Way SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.059.21 I Gang Dolly Switch: Intermediate SCP SCF 903.070.21 Fan Isolator Switch, 3 Pole WHI SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.235.21 TV + FM + Satellite Outlet SCF 903.244.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5)					SCP
903.054.21					
903.059.21					
903.070.21 Fan Isolator Switch, 3 Pole 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF					
903.070.21 Fan Isolator Switch, 3 Pole WHI SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF	700.007.21	T dang Bony owners meaninedate			
903.070.21 Fan Isolator Switch, 3 Pole WHI SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF				\neg	
903.070.21 Fan Isolator Switch, 3 Pole WHI SCF 903.098.21.01 I Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 I Gang Speaker Outlet WHI SCF 903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.243.21.01 I Gang Data Socket, RJ11 WHI SCF 903.244.21.01 I Gang Data Socket, RJ12 WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCF 903.245.21.01 I Gang Data Socket, RJ45(Cat5)				0 0	
903.098.21.01 Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 Gang Speaker Outlet WHI SCF 903.234.21 Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.243.21.01 Gang Data Socket, RJ WHI SCF 903.243.21.01 Gang Data Socket, RJ WHI SCF 903.245.21.01 Gang Data Socket, RJ WHI SCF 903.245.21.01 Gang Data Socket, RJ SCF 903.245.21.01 Gang Data Socket			[
903.098.21.01 Gang Bell Switch, Push-to-Make SCP SCF 903.099.21.01 Gang Speaker Outlet WHI SCF 903.234.21 Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.243.21.01 Gang Data Socket, RJ WHI SCF 903.243.21.01 Gang Data Socket, RJ WHI SCF 903.245.21.01 Gang Data Socket, RJ WHI SCF 903.245.21.01 Gang Data Socket, RJ SCF 903.245.21.01 Gang Data Socket	002.070.21	5 1 1 · C · · · · 2 D ·	\A/I II		CCD
903.099.21.01 Gang Speaker Outlet					
903.234.21 I Gang Satellite Socket SCF 903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.243.21.01 Gang Data Socket, RJ11 WHI SCF 903.243.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF			3CF	WHI	
903.235.21 TV + Satellite Socket SCF 903.236.21 TV + FM + Satellite Outlet SCF 903.243.21.01 Gang Data Socket, RJ11 WHI SCF 903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF				*****	SCP
903.243.21.01 Gang Data Socket, RJ WHI SCF 903.244.21.01 Gang Data Socket, RJ WHI SCF 903.245.21.01 Gang Data Socket, RJ WHI SCF 903.245.21.01 Gang Data Socket, RJ SCF WHI SCF WH					SCP
903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF	903.236.21	TV + FM + Satellite Outlet			SCP
903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF					
903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF					
903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF					
903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF					
903.244.21.01 Gang Data Socket, RJ12 WHI SCF 903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF	903 243 21	OL I Gang Data Socket RIII		W/HI	SCP
903.245.21.01 Gang Data Socket, RJ45(Cat5) WHI SCF					SCP
					SCP
					SCP
	-				

Also Available:



904.023.10 (Shown Actual Size)



904.011.10



904.012.10




904.013.10



904.053.10



904.021.10




904.032.10



904.092.10



904.051.10



904.088.10



904.031.10



904.035.10



904.034.10



904.037.10




904.050.10



Material	Small Plate	Large Plate	Interior
Die Cast Brass	94 x 94mm	156 x 94mm	Wandsworth


904 Series: POLISHED BRASS



PB

BLK


PB




I Gang Switch, 20amp Double-Pole

904.020.10

904.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
904.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
904.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
904.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
904.026.10	I Gang Dimmer Switch 630 Watts 2 Way	PB
904.027.10	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	PB
904.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB




904.030.10	13amp Fuse-Only on 1 Gang Plate	BLK	BLK	PB
904.031.10	13amp Single Socket	PB	BLK	PB
904.091.10	13amp Single Socket	BLK	BLK	PB
904.032.10	13amp Double Socket	PB	BLK	PB
904.092.10	13amp Double Socket	BLK	BLK	PB
904.033.10	2 amp Single Socket		BLK	PB
904.034.10	5 amp Single Socket		BLK	PB




904.035.10	TV Outlet, Isolated	BLK	PB
904.035.10.NI	TV Outlet, Non Isolated		PB
904.036.10	TV/FM Outlet, Isolated	BLK	PB
904.036.10.NI	TV/FM Outlet Non-Isolated		PB
904.037.10	Telecom Outlet, Master	BLK	PB
904.038.10	Telecom Outlet, Slave	BLK	PB
904.039.10	Cord Outlet, Grommet on Plate	BLK	PB
904.047.10	Twin-Telecom, Master	BLK	PB
904.048.10	Twin-Telecom, Slave	BLK	PB

Couc	Description	Nockei		1 lacc
•				0
				Φ Φ 115V 235V Ø
904 040	In Cooker Switch 45amp D/P w	rith Neon RRW	BRW/	PR

904.040.10	Cooker Switch 45amp D/P with Neon	BRW	BRW	PB
904.040.10.SP	45amp Double-Pole Switch with Neon	RED	BLK	PB
904.041.10	Blanking Plate Single			PB
904.042.10	Blanking Plate Double			PB
904.046.10	Cooker Switch 45amp with I 3amp Socket		BRW	PB
904.050.10	Shaver Socket		BLK	PB



904.051.10	I Gang Dolly Switch 2 Way	PB	PB
904.052.10	2 Gang Dolly Switch 2 Way	PB	PB
904.053.10	3 Gang Dolly Switch 2 Way	PB	PB
904.054.10	4 Gang Dolly Switch 2 Way	PB	PB
904.059.10	I Gang Dolly Switch: Intermediate	PB	PB



904.070.10	Fan Isolator Switch, 3 Pole	BLK		PB
904.081.10	I Gang Architrave Switch, 84x32mm,	PB	BLK	PB
904.086.10	6 Gang Switch, 168x168mm	PB	BLK	PB
904.088.10	8 Gang Switch, 168x168mm	PB	BLK	PB




904.098.10.01	I Gang Bell Switch, Push-to-Make	PB	PB
904.099.10.01	I Gang Speaker Outlet	BLK	PB
904.234.10	I Gang Satellite Socket		PB
904.235.10	TV + Satellite Socket		PB
904.236.10	TV + FM + Satellite Outlet		PB



904.243.10.01	I Gang Data Socket, RJII	BLK	PB
904.244.10.01	I Gang Data Socket, RJ12	BLK	PB
904.245.10.01	I Gang Data Socket, RJ45(Cat5)	BLK	PB
904.245.10.02	2 Gang Data Socket, RI45(Cat5)	BLK	PB

Also Available:





905.032.10 (Shown Actual Size)


































M	aterial	Small Plate	Large Plate	Interior
Di	e Cast Brass	94 x 94mm	156 x 94mm	Wandsworth

905 Series: POLISHED BRASS





905.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
905.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
905.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
905.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
905.026.10	I Gang Dimmer Switch 630 Watts 2 Way	PB
905.027.10	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	PB
905.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB



905.030.10	13amp Fuse-Only on 1 Gang Plate	BLK	BLK	PB
905.031.10	13amp Single Socket	PB	BLK	PB
905.091.10	13amp Single Socket	BLK	BLK	PB
905.032.10	13amp Double Socket	PB	BLK	PB
905.092.10	13amp Double Socket	BLK	BLK	PB
905.033.10	2 amp Single Socket		BLK	PB
905.034.10	5 amp Single Socket		BLK	PB




905.035.10	TV Outlet, Isolated	BLK	PB
905.035.10.NI	TV Outlet, Non Isolated		PB
905.036.10	TV/FM Outlet, Isolated	BLK	PB
905.036.10.NI	TV/FM Outlet Non-Isolated		PB
905.037.10	Telecom Outlet, Master	BLK	PB
905.038.10	Telecom Outlet, Slave	BLK	PB
905.039.10	Cord Outlet, Grommet on Plate	BLK	PB
905.047.10	Twin-Telecom, Master	BLK	PB
905.048.10	Twin-Telecom, Slave	BLK	PB

Code	Description	Nockei IIII	ii iace
• •			Ø Q Q 138 239V Ø D Ø
005 040 1	O Caalean Suitab 4Fana D/F	Durish Name DD\A/ DD\A	// DD

905.040.10	Cooker Switch 45amp D/P with Neon	BRW	BRW	PB
905.040.10.SP	45amp Double-Pole Switch with Neon	RED	BLK	PB
905.041.10	Blanking Plate Single			PB
905.042.10	Blanking Plate Double			PB
905.046.10	Cooker Switch 45amp with I 3amp Socket		BRW	PB
905.050.10	Shaver Socket		BLK	PB




905.051.10	I Gang Dolly Switch 2 Way	PB	PB
905.052.10	2 Gang Dolly Switch 2 Way	PB	PB
905.053.10	3 Gang Dolly Switch 2 Way	PB	PB
905.054.10	4 Gang Dolly Switch 2 Way	PB	PB
905.059.10	I Gang Dolly Switch: Intermediate	PB	PB



905.070.10	Fan Isolator Switch, 3 Pole	BLK		PB
905.081.10	I Gang Architrave Switch, 84x32mm,	PB	BLK	PB
905.086.10	6 Gang Switch, 168x168mm	PB	BLK	PB
905.088.10	8 Gang Switch, 168x168mm	PB	BLK	PB



905.098.10.01	I Gang Bell Switch, Push-to-Make	PB	PB
905.099.10.01	I Gang Speaker Outlet	BLK	PB
905.234.10	I Gang Satellite Socket		PB
905.235.10	TV + Satellite Socket		PB
905.236.10	TV + FM + Satellite Outlet		PB



905.243.10.01	I Gang Data Socket, RJII	BLK	PB
905.244.10.01	I Gang Data Socket, RJI2	BLK	PB
905.245.10.01	I Gang Data Socket, RJ45(Cat5)	BLK	PB
905.245.10.02	2 Gang Data Socket, RI45(Cat5)	BLK	PB

Also Available:



906.022.10 (Shown Actual Size)



906.031.10 (Shown Actual Size)



906.001.10



906.011.10



906.012.10



906.081.10



906.013.10



906.052.10



906.023.10



906.033.10



906.092.10




906.098.10.01



906.027.10



906.035.10



906.032.10



906.040.10.SP



906.017.10



906.037.10



906.235.10



906.236.10



Material	Small Plate	Large Plate	Interior
2mm Brass Sheet	86 x 86mm	146 x 86mm	Wandsworth


Trim Plate 906.001.10 I Gang Switch 2 Way BLK BLK

906.001.10	I Gang Switch 2 Way	BLK	BLK	PB
906.002.10	2 Gang Switch 2 Way	BLK	BLK	PB
906.003.10	3 Gang Switch 2 Way	BLK	BLK	PB
906.004.10	4 Gang Switch 2 Way	BLK	BLK	PB
906.005.10	Spur Fused with Switch	BLK	BLK	PB
906.009.10	I Gang Switch: Intermediate	BLK	BLK	PB
906.011.10	I Gang Switch 2 Way	PB	BLK	PB
906.012.10	2 Gang Switch 2 Way	PB	BLK	PB
906.013.10	3 Gang Switch 2 Way	PB	BLK	PB
906.014.10	4 Gang Switch 2 Way	PB	BLK	PB
906.015.10	Spur Fused with Switch	PB	BLK	PB
906.016.10	Spur Fused with Switch & Cord Outlet	PB	BLK	PB
906.017.10	Spur Fused with Neon	PB	BLK	PB
906.018.10	Spur Fused with Neon & Cord Outlet	PB	BLK	PB
906.019.10	I Gang Switch: Intermediate	PB	BLK	PB
906.020.10	I Gang Switch, 20amp Double-Pole	PB	BLK	PB





906.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
906.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
906.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
906.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
906.026.10	I Gang Dimmer Switch 630 Watts 2 Way	PB
906.027.10	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	PB
906.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB




906.030.10	13amp Fuse-Only on 1 Gang Plate	BLK	BLK	PB
906.031.10	13amp Single Socket	PB	BLK	PB
906.091.10	13amp Single Socket	BLK	BLK	PB
906.032.10	13amp Double Socket	PB	BLK	PB
906.092.10	13amp Double Socket	BLK	BLK	PB
906.033.10	2 amp Single Socket		BLK	PB
906.034.10	5 amp Single Socket		BLK	PB




906.035.10	TV Outlet, Isolated	BLK	PB
906.035.10.NI	TV Outlet, Non Isolated		PB
906.036.10	TV/FM Outlet, Isolated	BLK	PB
906.036.10.NI	TV/FM Outlet Non-Isolated		PB
906.037.10	Telecom Outlet, Master	BLK	PB
906.038.10	Telecom Outlet, Slave	BLK	PB
906.039.10	Cord Outlet, Grommet on Plate	BLK	PB
906.047.10	Twin-Telecom, Master	BLK	PB
906.048.10	Twin-Telecom, Slave	BLK	PB

906 Series: POLISHED BRASS

Code	Description	Rocker	Trim	Plate
		• 📗 📭		© 115A D D D D D D D D D D D D D D D D D D D
906.040.10	Cooker Switch 45amp D/P with Neon	BRW	BRW	PB
906.040.10.5	SP 45amp Double-Pole Switch with Neon	RED	BLK	PB
906.041.10	Blanking Plate Single			PB
906.042.10	Blanking Plate Double			PB
906.046.10	Cooker Switch 45amp with 13amp Soc	ket	BRW	PB
906.050.10	Shaver Socket		BLK	PB
P	99 99 999	@	ę	
906.051.10	I Gang Dolly Switch 2 Way	PB		PB
906.052.10	2 Gang Dolly Switch 2 Way	PB		PB
906.053.10	3 Gang Dolly Switch 2 Way	PB		PB
906.054.10	4 Gang Dolly Switch 2 Way	PB		PB
906.059.10	I Gang Dolly Switch: Intermediate	PB		PB



906.070.10	Fan Isolator Switch, 3 Pole	BLK		PB
906.081.10	I Gang Architrave Switch, 84x32mm,	PB	BLK	PB
906.082.10	2 Gang Architrave Switch, 146x38mm	PB	BLK	PB
906.086.10	6 Gang Switch, 146x146mm	PB	BLK	PB
906.088.10	8 Gang Switch, 146x146mm	PB	BLK	PB
	-			



906.098.10.01	I Gang Bell Switch, Push-to-Make	PB	PB
906.099.10.01	I Gang Speaker Outlet	BI	_K PB
906.234.10	I Gang Satellite Socket		PB
906.235.10	TV + Satellite Socket		PB
906.236.10	TV + FM + Satellite Outlet		PB



906.244.10.01 Gang Data Socket, RJ12	BLK	PB
906.245.10.01 Gang Data Socket, RJ45(Cat5)	BLK	PB
906.245.10.02 2 Gang Data Socket, RJ45(Cat5)	BLK	PB

Also Available:

Multiple gang Rocker switches, 9 to 12 gangs Multiple gang Dolly switches, 6 to 12 gangs Power Sockets for all Countries Voice/Data/Computer Sockets







2

906.070.20



906.037.20

8

1


906.040.20.SP

906.047.20


906.035.20

Material	Small Plate	Large Plate	Interior
2mm Brass Sheet	86 x 86mm	146 x 86mm	Wandsworth


Rocker Trim Plate Description Code



906.011.20	I Gang Switch 2 Way	CP	WHI	СР
906.012.20	2 Gang Switch 2 Way	CP	WHI	СР
906.013.20	3 Gang Switch 2 Way	CP	WHI	CP
906.014.20	4 Gang Switch 2 Way	CP	WHI	CP
906.015.20	Spur Fused with Switch	CP	WHI	CP
906.016.20	Spur Fused with Switch & Cord Outlet	CP	WHI	СР
906.017.20	Spur Fused with Neon	CP	WHI	CP
906.018.20	Spur Fused with Neon & Cord Outlet	CP	WHI	СР
906.019.20	I Gang Switch: Intermediate	CP	WHI	CP
906.020.20	I Gang Switch, 20amp Double-Pole	CP	WHI	CP



906.021.20	I Gang Dimmer Switch 400 Watts 2 Way	СР
906.022.20	2 Gang Dimmer Switch 400 Watts 2 Way	CP
906.023.20	3 Gang Dimmer Switch 400 Watts 2 Way	CP
906.024.20	4 Gang Dimmer Switch 400 Watts 2 Way	CP
906.026.20	I Gang Dimmer Switch 630 Watts 2 Way	CP
906.027.20	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	CP
906.028.20	I Gang Dimmer Switch 1000 Watts 2 Way	CP
	•	



906.030.20	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	CP
906.031.20	13amp Single Socket	CP	WHI	CP
906.032.20	13amp Double Socket	CP	WHI	CP
906.033.20	2 amp Single Socket		WHI	CP
906.034.20	5 amp Single Socket		WHI	CP




906.035.20	TV Outlet, Isolated	WHI	СР
906.035.20.NI	TV Outlet, Non Isolated		CP
906.036.20	TV/FM Outlet, Isolated	WHI	СР
906.036.20.NI	TV/FM Outlet Non-Isolated		СР
906.037.20	Telecom Outlet, Master	WHI	СР
906.038.20	Telecom Outlet, Slave	WHI	СР
906.039.20	Cord Outlet, Grommet on Plate	WHI	СР
906.047.20	Twin-Telecom, Master	WHI	СР
906.048.20	Twin-Telecom, Slave	WHI	CP

906 Series: POLISHED CHROME

Code	Description	Rocker	Trim	Plate
Code	Description	Nocker	111111	riate
•				Ø
004 040 20	Carlos Critich Africa D/D with No	eon WHI	WHI	
906.040.20	Cooker Switch 45amp D/P with Ne			CP CP
906.040.20.		eon RED	WHI	СР
906.041.20	Blanking Plate Single			СР
906.042.20	Blanking Plate Double			CP
906.046.20	Cooker Switch 45amp with 13amp	Socket	WHI	СР
906.050.20	Shaver Socket		WHI	CP
%	99 99 99 99	999	%	
906.051.20	I Gang Dolly Switch 2 Way	CP		CP
906.052.20	2 Gang Dolly Switch 2 Way	CP		CP
906.053.20	3 Gang Dolly Switch 2 Way	CP		CP
906.054.20	4 Gang Dolly Switch 2 Way	СР		СР
906.059.20	I Gang Dolly Switch: Intermediate	СР		СР

906.070.20	Fan Isolator Switch, 3 Pole	WHI		СР
906.081.20	I Gang Architrave Switch, 84x32mm,	CP	WHI	СР
906.082.20	2 Gang Architrave Switch, 146x38mm	CP	WHI	СР
906.086.20	6 Gang Switch, 146x146mm	CP	WHI	CP
906.088.20	8 Gang Switch, 146x146mm	CP	WHI	CP



906.098.20.01	I Gang Bell Switch, Push-to-Make	CP	CP
906.099.20.01	I Gang Speaker Outlet	WHI	СР
906.234.20	I Gang Satellite Socket		СР
906.235.20	TV + Satellite Socket		СР
906.236.20	TV + FM + Satellite Outlet		СР



I Gang Data Socket, RJII	WHI	CP
I Gang Data Socket, RJI2	WHI	CP
I Gang Data Socket, RJ45(Cat5)	WHI	СР
2 Gang Data Socket, RJ45(Cat5)	WHI	CP
	I Gang Data Socket, RJII I Gang Data Socket, RJI2 I Gang Data Socket, RJ45(Cat5) 2 Gang Data Socket, RJ45(Cat5)	I Gang Data Socket, RJ45(Cat5) WHI

Also Available:

Multiple gang Rocker switches, 9 to 12 gangs Multiple gang Dolly switches, 6 to 12 gangs Power Sockets for all Countries Voice/Data/Computer Sockets


















906.070.21

Material	Small Plate	Large Plate	Interior
2mm Brass Sheet	86 x 86mm	146 x 86mm	Wandsworth


		ı		
906.011.21	I Gang Switch 2 Way	SCP	WHI	SCP
906.012.21	2 Gang Switch 2 Way	SCP	WHI	SCP
906.013.21	3 Gang Switch 2 Way	SCP	WHI	SCP
906.014.21	4 Gang Switch 2 Way	SCP	WHI	SCP
906.015.21	Spur Fused with Switch	SCP	WHI	SCP
906.016.21	Spur Fused with Switch & Cord Outlet	SCP	WHI	SCP
906.017.21	Spur Fused with Neon	SCP	WHI	SCP
906.018.21	Spur Fused with Neon & Cord Outlet	SCP	WHI	SCP
906.019.21	I Gang Switch: Intermediate	SCP	WHI	SCP
906.020.21	I Gang Switch, 20amp Double-Pole	SCP	WHI	SCP
-				



906.021.21	I Gang Dimmer Switch 400 Watts 2 Way	SCP
906.022.21	2 Gang Dimmer Switch 400 Watts 2 Way	SCP
906.023.21	3 Gang Dimmer Switch 400 Watts 2 Way	SCP
906.024.21	4 Gang Dimmer Switch 400 Watts 2 Way	SCP
906.026.21	I Gang Dimmer Switch 630 Watts 2 Way	SCP
906.027.21	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	SCP
906.028.21	I Gang Dimmer Switch 1000 Watts 2 Way	SCP
	•	



906.030.21	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SCP
906.031.21	13amp Single Socket	SCP	WHI	SCP
906.032.21	13amp Double Socket	SCP	WHI	SCP
906.033.21	2 amp Single Socket		WHI	SCP
906.034.21	5 amp Single Socket		WHI	SCP



906.035.21	TV Outlet, Isolated	WHI	SCP
906.035.21.NI	TV Outlet, Non Isolated		SCP
906.036.21	TV/FM Outlet, Isolated	WHI	SCP
906.036.21.NI	TV/FM Outlet Non-Isolated		SCP
906.037.21	Telecom Outlet, Master	WHI	SCP
906.038.21	Telecom Outlet, Slave	WHI	SCP
906.039.21	Cord Outlet, Grommet on Plate	WHI	SCP
906.047.21	Twin-Telecom, Master	WHI	SCP
906.048.21	Twin-Telecom, Slave	WHI	SCP


906 Series: SATIN CHROME

Code	Description	Rocker	Trim	Plate
				Ø Q Q 115V D D
0				0
906.040.21	Cooker Switch 45amp D/P with No	eon WHI	WHI	SCP
906.040.21.			WHI	SCP
906.041.21	Blanking Plate Single			SCP
906.042.21	Blanking Plate Double			SCP
906.046.21	Cooker Switch 45amp with I 3amp	Socket	WHI	SCP
906.050.21	Shaver Socket		WHI	SCP
%	ଡ଼ଡ଼ା <mark>ଡ଼ଡ଼</mark> ଡ଼	999	ଡ଼	
906.051.21	I Gang Dolly Switch 2 Way	SCP		SCP
906.052.21	2 Gang Dolly Switch 2 Way	SCP		SCP
906.053.21	3 Gang Dolly Switch 2 Way	SCP		SCP
906.054.21	4 Gang Dolly Switch 2 Way	SCP		SCP
906.059.21	I Gang Dolly Switch: Intermediate	SCP		SCP
S				

906.070.21	Fan Isolator Switch, 3 Pole	WHI		SCP
906.081.21	I Gang Architrave Switch, 84x32mm,	SCP	WHI	SCP
906.082.21	2 Gang Architrave Switch, 146x38mm	SCP	WHI	SCP
906.086.21	6 Gang Switch, 146x146mm	SCP	WHI	SCP
906.088.21	8 Gang Switch, 146x146mm	SCP	WHI	SCP




906.098.21.01	I Gang Bell Switch, Push-to-Make	SCP		SCP
906.099.21.01	I Gang Speaker Outlet		WHI	SCP
906.234.21	I Gang Satellite Socket			SCP
906.235.21	TV + Satellite Socket			SCP
906.236.21	TV + FM + Satellite Outlet			SCP



I Gang Data Socket, RJII	WHI	SCP
I Gang Data Socket, RJ12	WHI	SCP
I Gang Data Socket, RJ45(Cat5)	WHI	SCP
2 Gang Data Socket, RJ45(Cat5)	WHI	SCP
	Gang Data Socket, RJ11 Gang Data Socket, RJ12 Gang Data Socket, RJ45(Cat5) 2 Gang Data Socket, RJ45(Cat5)	I Gang Data Socket, RJ45(Cat5) WHI

Also Available:

Multiple gang Rocker switches, 9 to 12 gangs Multiple gang Dolly switches, 6 to 12 gangs Power Sockets for all Countries Voice/Data/Computer Sockets





•

906.235.51

906.038.51


906.050.51




10

Material	Small Plate	Large Plate	Interior
2mm Stainless Steel	86 x 86mm	146 x 86mm	Wandsworth


906.011.51	I Gang Switch 2 Way	SCP	WHI	SSS
906.012.51	2 Gang Switch 2 Way	SCP	WHI	SSS
906.013.51	3 Gang Switch 2 Way	SCP	WHI	SSS
906.014.51	4 Gang Switch 2 Way	SCP	WHI	SSS
906.015.51	Spur Fused with Switch	SCP	WHI	SSS
906.016.51	Spur Fused with Switch & Cord Outlet	SCP	WHI	SSS
906.017.51	Spur Fused with Neon	SCP	WHI	SSS
906.018.51	Spur Fused with Neon & Cord Outlet	SCP	WHI	SSS
906.019.51	I Gang Switch: Intermediate	SCP	WHI	SSS
906.020.51	I Gang Switch, 20amp Double-Pole	SCP	WHI	SSS



906.021.51	I Gang Dimmer Switch 400 Watts 2 Way	SSS
906.022.51	2 Gang Dimmer Switch 400 Watts 2 Way	SSS
906.023.51	3 Gang Dimmer Switch 400 Watts 2 Way	SSS
906.024.51	4 Gang Dimmer Switch 400 Watts 2 Way	SSS
906.026.51	I Gang Dimmer Switch 630 Watts 2 Way	SSS
906.027.51	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	SSS
906.028.51	I Gang Dimmer Switch 1000 Watts on Large Plate2 Way	SSS



906.030.51	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SSS
906.031.51	13amp Single Socket	SCP	WHI	SSS
906.032.51	13amp Double Socket	SCP	WHI	SSS
906.033.51	2 amp Single Socket		WHI	SSS
906.034.51	5 amp Single Socket		WHI	SSS




906.035.51	TV Outlet, Isolated	WHI	SSS
906.035.51.NI	TV Outlet, Non Isolated		SSS
906.036.51	TV/FM Outlet, Isolated	WHI	SSS
906.036.51.NI	TV/FM Outlet Non-Isolated		SSS
906.037.51	Telecom Outlet, Master	WHI	SSS
906.038.51	Telecom Outlet, Slave	WHI	SSS
906.039.51	Cord Outlet, Grommet on Plate	WHI	SSS
906.047.51	Twin-Telecom, Master	WHI	SSS
906.048.51	Twin-Telecom, Slave	WHI	SSS


906 Series: SATIN STAINLESS STEEL

C-d-	Description		Rocker	Trim	DI-4-
Code	Description		Kocker	I rim	Plate
• [0 0			Ø
906.040.51	Cooker Switch 45a	mp D/P with Neo	n WHI	WHI	SSS
906.040.51.	SP 45amp Double-Pole	Switch with Nec	on RED	WHI	SSS
906.041.51	Blanking Plate Single	:			SSS
906.042.51	Blanking Plate Doub	ole			SSS
906.046.51	Cooker Switch with	13amp Socket	WHI	WHI	SSS
906.050.51	Shaver Socket			WHI	SSS
%	ଡ଼ଡ଼ ଡ଼	ଡ଼ ଜ୍ୟୁ	P P		
906.051.51	I Gang Dolly Switch	n 2 Way	SCP		SSS
906.052.51	2 Gang Dolly Switch	n 2 Way	SCP		SSS
906.053.51	3 Gang Dolly Switch	n 2 Way	SCP		SSS
906.054.51	4 Gang Dolly Switch	n 2 Way	SCP		SSS
906.059.51	I Gang Dolly Switch	n: Intermediate	SCP		SSS

906.070.51	Fan Isolator Switch, 3 Pole	WHI		SSS
906.081.51	I Gang Architrave Switch, 82x38mm,	SCP	WHI	SSS
906.082.51	2 Gang Architrave Switch, 146x38mm	SCP	WHI	SSS
906.086.51	6 Gang Switch, 146x 146mm	SCP	WHI	SSS
906.088.51	8 Gang Switch, 146x 146mm	SCP	WHI	SSS



906.098.51.01	i Gang Bell Switch, Push-to-Make	SCP	222
906.099.51.01	I Gang Speaker Outlet	WHI	SSS
906.234.51	I Gang Satellite Socket		SSS
906.235.51	TV + Satellite Socket		SSS
906.236.51	TV + FM + Satellite Outlet		SSS



906.243.51.01	I Gang Data Socket, RJII	WHI	SSS
906.244.51.01	I Gang Data Socket, RJ12	WHI	SSS
906.245.51.01	I Gang Data Socket, RJ45(Cat5)	WHI	SSS
906.245.51.02	2 Gang Data Socket, RJ45(Cat5)	WHI	SSS

Also Available:





909.032.10 (Shown Actual Size)



909.002.10

909.011.10



909.014.10







909.015.10 909.052.10



909.040.10.SP





909.027.10



909.092.10



909.070.10



909.236.10







909.033.10



909.245.10.01



909.050.10


909.031.10



Material	Small Plate	Large Plate	Interior
Forged Brass	86 x 86mm	146 x 86mm	Wandsworth


Rocker Trim Plate Code Description

		J		
909.001.10	I Gang Switch 2 Way	BLK	BLK	PB
909.002.10	2 Gang Switch 2 Way	BLK	BLK	PB
909.003.10	3 Gang Switch 2 Way	BLK	BLK	PB
909.004.10	4 Gang Switch 2 Way	BLK	BLK	PB
909.005.10	Spur Fused with Switch	BLK	BLK	PB
909.009.10	I Gang Switch: Intermediate	BLK	BLK	PB
909.011.10	I Gang Switch 2 Way	PB	BLK	PB
909.012.10	2 Gang Switch 2 Way	PB	BLK	PB
909.013.10	3 Gang Switch 2 Way	PB	BLK	PB
909.014.10	4 Gang Switch 2 Way	PB	BLK	PB
909.015.10	Spur Fused with Switch	PB	BLK	PB
909.016.10	Spur Fused with Switch & Cord Outlet	PB	BLK	PB
909.017.10	Spur Fused with Neon	PB	BLK	PB
909.018.10	Spur Fused with Neon & Cord Outlet	PB	BLK	PB
909.019.10	I Gang Switch: Intermediate	PB	BLK	PB
909.020.10	I Gang Switch, 20amp Double-Pole	PB	BLK	PB





909.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
909.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
909.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
909.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
909.026.10	I Gang Dimmer Switch 630 Watts 2 Way	PB
909.027.10	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	PB
909.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB




909.030.10	13amp Fuse-Only on 1 Gang Plate	BLK	BLK	PB
909.031.10	13amp Single Socket	PB	BLK	PB
909.091.10	13amp Single Socket	BLK	BLK	PB
909.032.10	13amp Double Socket	PB	BLK	PB
909.092.10	13amp Double Socket	BLK	BLK	PB
909.033.10	2 amp Single Socket		BLK	PB
909.034.10	5 amp Single Socket		BLK	PB



909.035.10	TV Outlet, Isolated	BLK	PB
909.035.10.NI	TV Outlet, Non Isolated		PB
909.036.10	TV/FM Outlet, Isolated	BLK	PB
909.036.10.NI	TV/FM Outlet Non-Isolated		PB
909.037.10	Telecom Outlet, Master	BLK	PB
909.038.10	Telecom Outlet, Slave	BLK	PB
909.039.10	Cord Outlet, Grommet on Plate	BLK	PB
909.047.10	Twin-Telecom, Master	BLK	PB
909.048.10	Twin-Telecom, Slave	BLK	PB

909 Series: POLISHED BRASS

Code	Description	Rocker	Trim	Plate
• • • • • • • • • • • • • • • • • • •				Ø
909.040.10	Cooker Switch 45amp D/P with Neon	BRW	BRW	PB
909.040.10.51	P 45amp Double-Pole Switch with Neon	RED	BLK	PB
909.041.10	Blanking Plate Single			PB
909.042.10	Blanking Plate Double			PB
909.046.10	Cooker Switch 45amp with I 3amp Sock	et	BRW	PB
909.050.10	Shaver Socket		BLK	PB
9	99 999	@		
909.051.10	I Gang Dolly Switch 2 Way	PB		PB
909.052.10	2 Gang Dolly Switch 2 Way	PB		PB
909.053.10	3 Gang Dolly Switch 2 Way	PB		PB
909.054.10	4 Gang Dolly Switch 2 Way	PB		PB




I Gang Dolly Switch: Intermediate

909.059.10

909.070.10	Fan Isolator Switch, 3 Pole	BLK		PB
909.081.10	I Gang Architrave Switch, 84x32mm,	PB	BLK	PB
909.086.10	6 Gang Switch, 168x168mm	PB	BLK	PB
909.088.10	8 Gang Switch, 168x168mm	PB	BLK	PB



909.098.10.01	I Gang Bell Switch, Push-to-Make	PB	PB
909.099.10.01	I Gang Speaker Outlet	BLK	PB
909.234.10	I Gang Satellite Socket		PB
909.235.10	TV + Satellite Socket		PB
909.236.10	TV + FM + Satellite Outlet		PB



909.243.10.01	I Gang Data Socket, RJII	BLK	PB
909.244.10.01	I Gang Data Socket, RJ12	BLK	PB
909.245.10.01	I Gang Data Socket, RJ45(Cat5)	BLK	PB
909.245.10.02	2 Gang Data Socket, RI45(Cat5)	BLK	PB

Also Available:

Power Sockets for all Countries Voice/Data/Computer Sockets

PB

РВ





909.012.20 (Shown Actual Size)



909.031.20 (Shown Actual Size)



909.011.20



909.014.20



909.053.20



909.052.20




909.022.20



909.024.20





909.032.20



909.033.20



909.040.20



909.017.20



909.037.20



909.070.20



909.081.20



909.036.20.NI



909.234.20




909.050.20



Material	Small Plate	Large Plate	Interior
Forged Brass	86 x 86mm	146 x 86mm	Wandsworth


909 Series: POLISHED CHROME



909.040.20	Cooker Switch 45amp D/P with Neon	WHI	WHI	CP
909.040.20.SP	45amp Double-Pole Switch with Neon	RED	WHI	CP
909.041.20	Blanking Plate Single			CP
909.042.20	Blanking Plate Double			CP
909.046.20	Cooker Switch 45amp with I 3amp Socket		WHI	CP
909.050.20	Shaver Socket		WHI	CP

9 9 9	% %	ଡ଼ ଡ଼ଡ଼	9
-------	-------------	----------------	---


909.051.20	I Gang Dolly Switch 2 Way	СР	CP
909.052.20	2 Gang Dolly Switch 2 Way	СР	СР
909.053.20	3 Gang Dolly Switch 2 Way	СР	CP
909.054.20	4 Gang Dolly Switch 2 Way	СР	CP
909.059.20	I Gang Dolly Switch: Intermediate	СР	СР



909.070.20	Fan Isolator Switch, 3 Pole	WHI		CP
909.081.20	I Gang Architrave Switch, 84x32mm,	CP	WHI	CP
909.086.20	6 Gang Switch, 168x168mm	CP	WHI	CP
909.088.20	8 Gang Switch, 168x168mm	CP	WHI	CP



909.098.20.01	I Gang Bell Switch, Push-to-Make	CP	CP
909.099.20.01	I Gang Speaker Outlet	٧	VHI CP
909.234.20	I Gang Satellite Socket		СР
909.235.20	TV + Satellite Socket		СР
909.236.20	TV + FM + Satellite Outlet		СР



СР

CP

CP

СР

WHI

WHI

WHI

WHI

909.243.20.01	I Gang Data Socket, RJII	WHI	СР
909.244.20.01	I Gang Data Socket, RJ12	WHI	СР
909.245.20.01	I Gang Data Socket, RJ45(Cat5)	WHI	СР
909.245.20.02	2 Gang Data Socket, RJ45(Cat5)	WHI	СР

Also Available:

Power Sockets for all Countries Voice/Data/Computer Sockets

Code	Description Ro	cker	Trim	Plate
		J		
P O O				
909.011.20	I Gang Switch 2 Way	СР	WHI	СР
909.012.20	ů ,	СР	WHI	СР
909.013.20	<u> </u>	CP	WHI	СР
909.014.20	,	CP	WHI	CP
909.015.20	· · · · · · · · · · · · · · · · · · ·	CP	WHI	CP
909.016.20		CP	WHI	CP
909.017.20		CP CP	WHI	CP CP
909.018.20		CP	WHI	CP CP
909.020.20	-	CP	WHI	CP
707.020.20	1 dang owners, Zoamp Boable 1 ole	<u> </u>	*****	
• 0 •	· O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O O · O O · O O · O O · O O · O O · O O · O O · O · O O · O · O O · O · O O ·		ALSO AVAILABLE Low Voltage	
· O •				
909.021.20	I Gang Dimmer Switch 400 Watts 2 Way			СР
909.022.20	2 Gang Dimmer Switch 400 Watts 2 Way			CP
909.023.20	, ,			CP
909.024.20	, ,			CP
909.026.20	, ,	Dlasa	2 \A/	CP CP
909.027.20 909.028.20	<u> </u>			CP CP
707.020.20	1 Gang Dilliner Switch 1000 Watts on Larg	e i iace	z v v ay	
⊗ FJ ⊗				
909.030.20	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	СР
909.031.20		CP	WHI	СР
909.032.20		CP	WHI	СР
909.033.20	1 0		WHI	CP
909.034.20	5 amp Single Socket		WHI	CP
· • •				
909.035.20	TV Outlet, Isolated		WHI	СР
909.035.20			_	СР
909.036.20			WHI	CP
909.036.20				СР
909.037.20	Telecom Outlet, Master		WHI	CP

909.038.20

909.039.20

909.047.20


909.048.20

Telecom Outlet, Slave

Twin-Telecom, Master

Twin-Telecom, Slave

Cord Outlet, Grommet on Plate





909.042.21

909.035.21

909.235.21

909.050.21



909.031.21

909.040.21.SP 909.048.21




909.032.21

7


Material	Small Plate	Large Plate	Interior
Forged Brass	86 x 86mm	146 x 86mm	Wandsworth

Rocker Trim Plate Code Description © FUSE O

909.011.21	I Gang Switch 2 Way	SCP	WHI	SCP
909.012.21	2 Gang Switch 2 Way	SCP	WHI	SCP
909.013.21	3 Gang Switch 2 Way	SCP	WHI	SCP
909.014.21	4 Gang Switch 2 Way	SCP	WHI	SCP
909.015.21	Spur Fused with Switch	SCP	WHI	SCP
909.016.21	Spur Fused with Switch & Cord Outlet	SCP	WHI	SCP
909.017.21	Spur Fused with Neon	SCP	WHI	SCP
909.018.21	Spur Fused with Neon & Cord Outlet	SCP	WHI	SCP
909.019.21	I Gang Switch: Intermediate	SCP	WHI	SCP
909.020.21	I Gang Switch, 20amp Double-Pole	SCP	WHI	SCP



909.021.21	I Gang Dimmer Switch 400 Watts 2 Way	SCP
909.022.21	2 Gang Dimmer Switch 400 Watts 2 Way	SCP
909.023.21	3 Gang Dimmer Switch 400 Watts 2 Way	SCP
909.024.21	4 Gang Dimmer Switch 400 Watts 2 Way	SCP
909.026.21	I Gang Dimmer Switch 630 Watts 2 Way	SCP
909.027.21	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	SCP
909.028.21	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SCP




909.030.21	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SCP
909.031.21	13amp Single Socket	SCP	WHI	SCP
909.032.21	13amp Double Socket	SCP	WHI	SCP
909.033.21	2 amp Single Socket		WHI	SCP
909.034.21	5 amp Single Socket		WHI	SCP



909.035.21	TV Outlet, Isolated	WHI	SCP
909.035.21.NI	TV Outlet, Non Isolated		SCP
909.036.21	TV/FM Outlet, Isolated	WHI	SCP
909.036.21.NI	TV/FM Outlet Non-Isolated		SCP
909.037.21	Telecom Outlet, Master	WHI	SCP
909.038.21	Telecom Outlet, Slave	WHI	SCP
909.039.21	Cord Outlet, Grommet on Plate	WHI	SCP
909.047.21	Twin-Telecom, Master	WHI	SCP
909.048.21	Twin-Telecom, Slave	WHI	SCP

909 Series: SATIN CHROME



909.070.21	Fan Isolator Switch, 3 Pole	WHI		SCP
909.081.21	I Gang Architrave Switch, 84x32mm,	SCP	WHI	SCP
909.086.21	6 Gang Switch, 168x168mm	SCP	WHI	SCP
909.088.21	8 Gang Switch, 168x168mm	SCP	WHI	SCP



909.098.21.01	I Gang Bell Switch, Push-to-Make	SCP		SCP
909.099.21.01	I Gang Speaker Outlet		WHI	SCP
909.234.21	I Gang Satellite Socket			SCP
909.235.21	TV + Satellite Socket			SCP
909.236.21	TV + FM + Satellite Outlet			SCP



909.243.21.01	I Gang Data Socket, RJII	WHI	SCP
909.244.21.01	I Gang Data Socket, RJ12	WHI	SCP
909.245.21.01	I Gang Data Socket, RJ45(Cat5)	WHI	SCP
909.245.21.02	2 Gang Data Socket, RI45(Cat5)	WHI	SCP

Also Available:



909.053.22 (Shown Actual Size)





909.013.22







909.021.22



909.012.22



909.015.22



909.081.22



909.032.22



909.031.22







909.033.22



909.040.22



909.038.22



909.047.22



909.236.22




909.050.22




Material	Small Plate	Large Plate	Interior
Forged Brass	86 x 86mm	146 x 86mm	Wandsworth

Rocker Trim Plate Description I Gang Switch 2 Way 909.011.22 CP WHI SC/CP 909.012.22 2 Gang Switch 2 Way CP WHI SC/CP СР 909.013.22 WHI SC/CP 3 Gang Switch 2 Way 909.014.22 4 Gang Switch 2 Way СР WHI SC/CP 909.015.22 Spur Fused with Switch CP WHI SC/CP 909.016.22 Spur Fused with Switch & Cord Outlet CP WHI SC/CP 909.017.22 CP WHI SC/CP Spur Fused with Neon 909.018.22 Spur Fused with Neon & Cord Outlet CP WHI SC/CP 909.019.22 I Gang Switch: Intermediate CP WHI SC/CP 909.020.22 I Gang Switch, 20amp Double-Pole CP WHI SC/CP



909.021.22	I Gang Dimmer Switch 400 Watts 2 Way	SC/CP
909.022.22	2 Gang Dimmer Switch 400 Watts 2 Way	SC/CP
909.023.22	3 Gang Dimmer Switch 400 Watts 2 Way	SC/CP
909.024.22	4 Gang Dimmer Switch 400 Watts 2 Way	SC/CP
909.026.22	I Gang Dimmer Switch 630 Watts 2 Way	SC/CP
909.027.22	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	SC/CP
909.028.22	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SC/CP
'		



909.030.22	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SC/CP
909.031.22	13amp Single Socket	CP	WHI	SC/CP
909.032.22	13amp Double Socket	CP	WHI	SC/CP
909.033.22	2 amp Single Socket		WHI	SC/CP
909.034.22	5 amp Single Socket		WHI	SC/CP




909.035.22	TV Outlet, Isolated	WHI	SC/CP
909.035.22.NI	TV Outlet, Non Isolated		SC/CP
909.036.22	TV/FM Outlet, Isolated	WHI	SC/CP
909.036.22.NI	TV/FM Outlet Non-Isolated		SC/CP
909.037.22	Telecom Outlet, Master	WHI	SC/CP
909.038.22	Telecom Outlet, Slave	WHI	SC/CP
909.039.22	Cord Outlet, Grommet on Plate	WHI	SC/CP
909.047.22	Twin-Telecom, Master	WHI	SC/CP
909.048.22	Twin-Telecom, Slave	WHI	SC/CP

909 Series: SATIN CHROME / POLISHED CHROME


Code	Description	Rocker	Trim	Plate
				Ø D D D
909.040.22	Cooker Switch 45amp D/P with Neon	WHI	WHI	SC/CP
909.040.22.5		RED	WHI	SC/CP
909.041.22	Blanking Plate Single	I I I	*****	SC/CP
909.042.22	Blanking Plate Double			SC/CP
909.046.22	Cooker Switch 45amp with I 3amp Sock	et	WHI	SC/CP
909.050.22	Shaver Socket		WHI	SC/CP
9	99 99 999	@	?	
909.051.22	I Gang Dolly Switch 2 Way	CP		SC/CP
909.052.22	2 Gang Dolly Switch 2 Way	CP		SC/CP
909.053.22	3 Gang Dolly Switch 2 Way	CP		SC/CP
909.054.22	4 Gang Dolly Switch 2 Way	CP		SC/CP
909.059.22	I Gang Dolly Switch: Intermediate	СР		SC/CP



909.070.22	Fan Isolator Switch, 3 Pole	WHI		SC/CP
909.081.22	I Gang Architrave Switch, 84x32mm,	CP	WHI	SC/CP
909.086.22	6 Gang Switch, 168x168mm	CP	WHI	SC/CP
909 088 22	8 Gang Switch 168x168mm	СР	WHI	SC/CP



909.098.22.01	I Gang Bell Switch, Push-to-Make	CP		SC/CP
909.099.22.01	I Gang Speaker Outlet		WHI	SC/CP
909.234.22	I Gang Satellite Socket			SC/CP
909.235.22	TV + Satellite Socket			SC/CP
909.236.22	TV + FM + Satellite Outlet			SC/CP



909.243.22.01	I Gang Data Socket, RJII	WHI	SC/CP
909.244.22.01	I Gang Data Socket, RJI2	WHI	SC/CP
909.245.22.01	I Gang Data Socket, RJ45(Cat5)	WHI	SC/CP
909.245.22.02	2 Gang Data Socket, RI45(Cat5)	WHI	SC/CP

Also Available:



909.011.31 (Shown Actual Size)



909.034.31 (Shown Actual Size)



909.012.31



909.013.31



909.053.31



909.052.31



909.022.31



909.023.31



909.027.31




909.015.31



909.031.31



909.032.31



909.042.31



909.040.31.SP



909.033.31



909.070.31



909.235.31




909.050.31




Material	Small Plate	Large Plate	Interior
Forged Brass	86 x 86mm	146 x 86mm	Wandsworth


Rocker Trim Plate Code Description I Gang Switch 2 Way 909.011.31 PB BLK SB/PB 909.012.31 2 Gang Switch 2 Way PB **BLK** SB/PB 909.013.31 РВ 3 Gang Switch 2 Way SB/PB **BLK** 909.014.31 4 Gang Switch 2 Way PB BLK SB/PB 909.015.31 Spur Fused with Switch PB BLK SB/PB 909.016.31 Spur Fused with Switch & Cord Outlet PB BLK SB/PB 909.017.31 PB BLK SB/PB Spur Fused with Neon 909.018.31 Spur Fused with Neon & Cord Outlet PB BLK SB/PB I Gang Switch: Intermediate 909.019.31 PB **BLK** SB/PB 909.020.31 I Gang Switch, 20amp Double-Pole PB BLK SB/PB



909.021.31	I Gang Dimmer Switch 400 Watts 2 Way	SB/PB
909.022.31	2 Gang Dimmer Switch 400 Watts 2 Way	SB/PB
909.023.31	3 Gang Dimmer Switch 400 Watts 2 Way	SB/PB
909.024.31	4 Gang Dimmer Switch 400 Watts 2 Way	SB/PB
909.026.31	I Gang Dimmer Switch 630 Watts 2 Way	SB/PB
909.027.31	2 Gang Dimmer Switch 400 Watts on Large Plate 2 Way	SB/PB
909.028.31	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SB/PB



909.030.31	13amp Fuse-Only on 1 Gang Plate	BLK	BLK	SB/PB
909.031.31	13amp Single Socket	PB	BLK	SB/PB
909.032.31	13amp Double Socket	PB	BLK	SB/PB
909.033.31	2 amp Single Socket		BLK	SB/PB
909.034.31	5 amp Single Socket		BLK	SB/PB
909.091.31	13amp Single Socket	BLK	BLK	SB/PB
909.092.31	13amp Double Socket	BLK	BLK	SB/PB




TV Outlet, Isolated	BLK	SB/PB
TV Outlet, Non Isolated		SB/PB
TV/FM Outlet, Isolated	BLK	SB/PB
TV/FM Outlet Non-Isolated		SB/PB
Telecom Outlet, Master	BLK	SB/PB
Telecom Outlet, Slave	BLK	SB/PB
Cord Outlet, Grommet on Plate	BLK	SB/PB
Twin-Telecom, Master	BLK	SB/PB
Twin-Telecom, Slave	BLK	SB/PB
	TV Outlet, Non Isolated TV/FM Outlet, Isolated TV/FM Outlet Non-Isolated Telecom Outlet, Master Telecom Outlet, Slave Cord Outlet, Grommet on Plate Twin-Telecom, Master	TV Outlet, Non Isolated TV/FM Outlet, Isolated BLK TV/FM Outlet Non-Isolated Telecom Outlet, Master BLK Telecom Outlet, Slave BLK Cord Outlet, Grommet on Plate BLK Twin-Telecom, Master BLK


909 Series: SATIN BRASS / POLISHED BRASS

Code	Description	Rocker	Trim	Plate
6				0
				-
Ш		$ \cdot $	_⊌。	Д 15V 255V В
0			의	اپ
909.040.31	Cooker Switch 45amp D/P with Neon	BRW	BRW	SB/PB
909.040.31		RED	BLK	SB/PB
909.041.31	Blanking Plate Single			SB/PB
909.042.31	Blanking Plate Double			SB/PB
909.046.31	Cooker Switch 45amp with 13amp Soc	ket	BRW	SB/PB
909.050.31	Shaver Socket		BLK	SB/PB
@	ଜଡ଼ ଜ ଜ ଜ ଜଜ଼ଜ	φ	@	
"		" L		
000 051 21				CD (DD
909.051.31	I Gang Dolly Switch 2 Way	PB		SB/PB
909.052.31	2 Gang Dolly Switch 2 Way	PB		SB/PB
909.053.31	3 Gang Dolly Switch 2 Way	PB		SB/PB
909.054.31	4 Gang Dolly Switch 2 Way	PB		SB/PB
909.059.31	I Gang Dolly Switch: Intermediate	PB		SB/PB
		\neg		
		9		
		9		

909.070.31	Fan Isolator Switch, 3 Pole	BLK		SB/PB
909.081.31	I Gang Architrave Switch, 84x32mm,	PB	BLK	SB/PB
909.086.31	6 Gang Switch, 168x168mm	PB	BLK	SB/PB
909.088.31	8 Gang Switch, 168x168mm	PB	BLK	SB/PB



909.098.31.01	I Gang Bell Switch, Push-to-Make	PB	SB/PB
909.099.31.01	I Gang Speaker Outlet	BLK	SB/PB
909.234.31	I Gang Satellite Socket		SB/PB
909.235.31	TV + Satellite Socket		SB/PB
909.236.31	TV + FM + Satellite Outlet		SB/PB



909.243.31.01	I Gang Data Socket, RJII	BLK	SB/PB
909.244.31.01	I Gang Data Socket, RJI2	BLK	SB/PB
909.245.31.01	I Gang Data Socket, RJ45(Cat5)	BLK	SB/PB
909.245.31.02	2 Gang Data Socket, RI45(Cat5)	BI K	SB/PB

Also Available:




922.012.10 (Shown Actual Size)



922.021.10 (Shown Actual Size)



922.001.10



922.003.10



922.014.10




922.063.10



922.091.10



922.092.10



922.032.10




922.031.10



922.034.10



922.023.10



922.046.10



922.035.10



922.047.10



922.081.10



922.245.10.02




922.050.10

Material	Small Plate	Large Plate	Interior
Die Cast Brass	92 x 92mm	150 x 92mm	Crabtree White


Code Description Rocker Trim Plate

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)			
922.001.10	I Gang Switch 2 Way	WHI	WHI	PB
922.002.10	2 Gang Switch 2 Way	WHI	WHI	PB
922.003.10	3 Gang Switch 2 Way	WHI	WHI	PB
922.004.10	4 Gang Switch 2 Way	WHI	WHI	PB
922.005.10	Spur Fused with Switch	WHI	WHI	PB
922.006.10	Spur Fused with Switch & Cord Outlet	WHI	WHI	PB
922.007.10	Spur Fused with Neon	WHI	WHI	PB
922.008.10	Spur Fused with Neon & Cord Outlet	WHI	WHI	PB
922.009.10	I Gang Switch: Intermediate	WHI	WHI	PB

INTERCHANGEABLE GRID SWITCHES (METAL ROCKER)				
922.011.10	I Gang Switch 2 Way	PB	WHI	PB
922.012.10	2 Gang Switch 2 Way	PB	WHI	PB
922.013.10	3 Gang Switch 2 Way	PB	WHI	PB
922.014.10	4 Gang Switch 2 Way	PB	WHI	PB
922.015.10	Spur Fused with Switch	PB	WHI	PB
922.017.10	Spur Fused with Neon	PB	WHI	PB
922.019.10	I Gang Switch: Intermediate	PB	WHI	PB
922.020.10	I Gang Switch, 20amp Double-Pole	PB	WHI	PB



922.021.10	I Gang Dimmer Switch 400 Watts 2 Way	PB
922.022.10	2 Gang Dimmer Switch 400 Watts 2 Way	PB
922.023.10	3 Gang Dimmer Switch 400 Watts 2 Way	PB
922.024.10	4 Gang Dimmer Switch 400 Watts 2 Way	PB
922.026.10	I Gang Dimmer Switch, 630 Watts 2 Way	PB
922.027.10	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	PB
922.028.10	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	PB
		_



922.030.10	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	PB
922.031.10	13amp Single Socket	PB	WHI	PB
922.032.10	13amp Double Socket	PB	WHI	PB
922.033.10	2 amp Single Socket		WHI	PB
922.034.10	5 amp Single Socket		WHI	PB
922.091.10	13amp Single Socket	WHI	WHI	PB
922.092.10	13amp Double Socket	WHI	WHI	PB

922.235.10

922.236.10

TV + Satellite Socket

922.245.10.01 | Gang Data Socket, RJ45(Cat5)

922.245.10.02 2 Gang Data Socket, RJ45(Cat5)

TV + FM + Satellite Outlet

922 Series: POLISHED BRASS

Code Description Rocker	Trim	Plate
922.035.10 TV Outlet, Isolated	WHI	PB
922.035.10.NI TV Outlet, Non Isolated	WHI	PB
922.036.10 TV/FM Outlet, Isolated 922.036.10.NI TV/FM Outlet Non-Isolated	WHI	PB PB
922.037.10 Telecom Outlet, Master	WHI	PB
922.038.10 Telecom Outlet, Plaster	WHI	PB
922.039.10 Cord Outlet, Grommet on Plate	WHI	PB
922.047.10 Twin-Telecom, Master	WHI	PB
922.048.10 Twin-Telecom, Slave	WHI	PB
, , , , , , , , , , , , , , , , , , , ,		
		Ø Q Q 115V 255V U U U
922.040.10 Cooker Switch 45amp D/P with Neon RED	WHI	PB
922.040.10.SP 45amp Double-Pole Switch with Neon RED	WHI	PB
922.041.10 Blanking Plate Single	*****	PB
922.042.10 Blanking Plate Double		PB
922.046.10 Cooker Switch 45amp with 13amp Socket RED	WHI	PB
922.050.10 Shaver Socket	WHI	PB
	•	•
922.061.10 I Gang Moulded Rocker Switch 2 Way WHI		PB
922.062.10 2 Gang Moulded Rocker Switch 2 Way WHI		PB
922.063.10 3 Gang Moulded Rocker Switch 2 Way WHI		PB
922.064.10 4 Gang Moulded Rocker Switch 2 Way WHI		PB
922.065.10 Spur Fused with Switch WHI		PB
922.069.10 I Gang Moulded Rocker Switch: Intermediate WH	I	PB
922.070.10 Fan Isolator Switch, 3 Pole WHI		PB
922.071.10 I Gang Architrave Switch, 86x37mm WHI	WHI	PB
922.081.10 I Gang Architrave Switch, 86x37mm PB	WHI	PB
922.099.10.01 Gang Speaker Outlet	WHI	PB
922.234.10 I Gang Satellite Socket		PB
922 225 IO TV + Satallita Sackat		DD

Also Available:

WHI

WHI

PB


PB

PB

РΒ



922.013.20 (Shown Actual Size)














922.235.20

Material	Small Plate	Large Plate	Interior
Die Cast Brass	92 x 92mm	150 x 92mm	Crabtree White


Rocker Trim Plate Code Description

INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)				
922.001.20	I Gang Switch 2 Way	WHI	WHI	CP
922.002.20	2 Gang Switch 2 Way	WHI	WHI	CP
922.003.20	3 Gang Switch 2 Way	WHI	WHI	CP
922.004.20	4 Gang Switch 2 Way	WHI	WHI	CP
922.005.20	Spur Fused with Switch	WHI	WHI	CP
922.006.20	Spur Fused with Switch & Cord Outlet	WHI	WHI	CP
922.007.20	Spur Fused with Neon	WHI	WHI	CP
922.008.20	Spur Fused with Neon & Cord Outlet	WHI	WHI	CP
922.009.20	I Gang Switch: Intermediate	WHI	WHI	CP

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (METAL ROCKER)				
922.011.20	I Gang Switch 2 Way	СР	WHI	CP	
922.012.20	2 Gang Switch 2 Way	СР	WHI	CP	
922.013.20	3 Gang Switch 2 Way	СР	WHI	CP	
922.014.20	4 Gang Switch 2 Way	СР	WHI	CP	
922.015.20	Spur Fused with Switch	СР	WHI	CP	
922.017.20	Spur Fused with Neon	СР	WHI	CP	
922.019.20	I Gang Switch: Intermediate	СР	WHI	CP	
922.020.20	I Gang Switch, 20amp Double-Pole	СР	WHI	CP	



922.021.20	I Gang Dimmer Switch 400 Watts 2 Way	СР
922.022.20	2 Gang Dimmer Switch 400 Watts 2 Way	CP
922.023.20	3 Gang Dimmer Switch 400 Watts 2 Way	CP
922.024.20	4 Gang Dimmer Switch 400 Watts 2 Way	CP
922.026.20	I Gang Dimmer Switch, 630 Watts 2 Way	CP
922.027.20	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	CP
922.028.20	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	CP



922.030.20	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	СР
922.031.20	13amp Single Socket	CP	WHI	СР
922.032.20	13amp Double Socket	CP	WHI	СР
922.033.20	2 amp Single Socket		WHI	СР
922.034.20	5 amp Single Socket		WHI	СР
922.091.20	13amp Single Socket	WHI	WHI	СР
922.092.20	13amp Double Socket	WHI	WHI	СР

922 Series: POLISHED CHROME

Code Description Rocker	Trim	Plate
922.035.20 TV Outlet, Isolated	WHI	СР
922.035.20. TV Outlet, Isolated	WHI	CP
922.036.20 TV/FM Outlet, Isolated	WHI	CP
922.036.20.NI TV/FM Outlet Non-Isolated	WHI	CP
922.037.20 Telecom Outlet, Master	WHI	СР
922.038.20 Telecom Outlet, Slave	WHI	СР
922.039.20 Cord Outlet, Grommet on Plate	WHI	CP
922.047.20 Twin-Telecom, Master	WHI	CP
922.048.20 Twin-Telecom, Slave	WHI	<u>CP</u>
		Ø
922.040.20 Cooker Switch 45amp D/P with Neon RED	WHI	СР
922.040.20.SP 45amp Double-Pole Switch with Neon RED	WHI	CP
922.041.20 Blanking Plate Single	**111	CP
922.042.20 Blanking Plate Double		CP
922.046.20 Cooker Switch 45amp with 13amp Socket RED	WHI	CP
922.050.20 Shaver Socket	WHI	CP
	 [
922.061.20 I Gang Moulded Rocker Switch 2 Way WHI		СР
922.062.20 2 Gang Moulded Rocker Switch 2 Way WHI		СР
922.063.20 3 Gang Moulded Rocker Switch 2 Way WHI		СР
922.064.20 4 Gang Moulded Rocker Switch 2 Way WHI		CP
922.065.20 Spur Fused with Switch WHI		СР
922.069.20 I Gang Moulded Rocker Switch: Intermediate WH	I	CP
922.070.20 Fan Isolator Switch, 3 Pole WHI		СР
922.071.20 I Gang Architrave Switch, 86x37mm WHI	WHI	СР
922.081.20 I Gang Architrave Switch, 86x37mm CP	WHI	СР

922.099.20.01 | Gang Speaker Outlet

I Gang Satellite Socket

TV + FM + Satellite Outlet

TV + Satellite Socket

922.245.20.01 | Gang Data Socket, RJ45(Cat5)

922.245.20.02 2 Gang Data Socket, RJ45(Cat5)

922.234.20

922.235.20

922.236.20

Also Available:

WHI

WHI

WHI

CP

CP

СР

CP CP

CP



922.032.22 (Shown Actual Size)



922.031.22

0

922.037.22

922.065.22

922.081.22

0

9

922.050.22



922.092.22

922.234.22

922.040.22.SP


922.091.22

Material	Small Plate	Large Plate	Interior
Die Cast Brass	92 x 92mm	150 x 92mm	Crabtree White


Rocker Trim Plate Code Description

INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)					
922.001.22	I Gang Switch 2 Way	WHI	WHI	SC/CP	
922.002.22	2 Gang Switch 2 Way	WHI	WHI	SC/CP	
922.003.22	3 Gang Switch 2 Way	WHI	WHI	SC/CP	
922.004.22	4 Gang Switch 2 Way	WHI	WHI	SC/CP	
922.005.22	Spur Fused with Switch	WHI	WHI	SC/CP	
922.006.22	Spur Fused with Switch & Cord Outlet	WHI	WHI	SC/CP	
922.007.22	Spur Fused with Neon	WHI	WHI	SC/CP	
922.008.22	Spur Fused with Neon & Cord Outlet	WHI	WHI	SC/CP	
922.009.22	I Gang Switch: Intermediate	WHI	WHI	SC/CP	

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (METAL ROCKER)				
922.011.22	I Gang Switch 2 Way	CP	WHI	SC/CP	
922.012.22	2 Gang Switch 2 Way	CP	WHI	SC/CP	
922.013.22	3 Gang Switch 2 Way	CP	WHI	SC/CP	
922.014.22	4 Gang Switch 2 Way	CP	WHI	SC/CP	
922.015.22	Spur Fused with Switch	СР	WHI	SC/CP	
922.017.22	Spur Fused with Neon	CP	WHI	SC/CP	
922.019.22	I Gang Switch: Intermediate	CP	WHI	SC/CP	
922.020.22	I Gang Switch, 20amp Double-Pole	CP	WHI	SC/CP	



922.021.22	I Gang Dimmer Switch 400 Watts 2 Way	SC/CP
922.022.22	2 Gang Dimmer Switch 400 Watts 2 Way	SC/CP
922.023.22	3 Gang Dimmer Switch 400 Watts 2 Way	SC/CP
922.024.22	4 Gang Dimmer Switch 400 Watts 2 Way	SC/CP
922.026.22	I Gang Dimmer Switch, 630 Watts 2 Way	SC/CP
922.027.22	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	SC/CP
922.028.22	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SC/CP



922.030.22	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SC/CP
922.031.22	13amp Single Socket	CP	WHI	SC/CP
922.032.22	13amp Double Socket	CP	WHI	SC/CP
922.033.22	2 amp Single Socket		WHI	SC/CP
922.034.22	5 amp Single Socket		WHI	SC/CP
922.091.22	13amp Single Socket	WHI	WHI	SC/CP
922.092.22	13amp Double Socket	WHI	WHI	SC/CP

922 Series: SATIN CHROME / POLISHED CHROME

Code Description	Rocker	Trim	Plate
]		
	J		
922.035.22 TV Outlet, Isolated		WHI	SC/CP
922.035.22 TV Outlet, Isolated		WHI	SC/CP
922.036.22 TV/FM Outlet, Isolated		WHI	SC/CP
922.036.22.NI TV/FM Outlet Non-Isolated		WHI	SC/CP
922.037.22 Telecom Outlet, Master		WHI	SC/CP
922.038.22 Telecom Outlet, Slave		WHI	SC/CP
922.039.22 Cord Outlet, Grommet on Plate		WHI	SC/CP
922.047.22 Twin-Telecom, Master		WHI	SC/CP
922.048.22 Twin-Telecom, Slave		WHI	SC/CP
8			0
			G G
			0
922.040.22 Cooker Switch 45amp D/P with Neon	RED	WHI	SC/CP
922.040.22.SP 45amp Double-Pole Switch with Neon	RED	WHI	SC/CP
922.041.22 Blanking Plate Single	KLD	***	SC/CP
922.042.22 Blanking Plate Double			SC/CP
922.046.22 Cooker Switch 45amp with 13amp Socker	t RED	WHI	SC/CP
922.050.22 Shaver Socket		WHI	SC/CP
			7
	SE	0	0
000 041 00 11 0 14 15 15 0 14 10 14	\ A / L I I		66/60
922.061.22 I Gang Moulded Rocker Switch 2 Way	WHI		SC/CP
922.062.22 2 Gang Moulded Rocker Switch 2 Way 922.063.22 3 Gang Moulded Rocker Switch 2 Way	WHI		SC/CP SC/CP
922.063.22 3 Gang Moulded Rocker Switch 2 Way 922.064.22 4 Gang Moulded Rocker Switch 2 Way	WHI		SC/CP
922.065.22 Spur Fused with Switch	WHI		SC/CP
922.069.22 I Gang Moulded Rocker Switch: Intermed		ı	SC/CP
6			
922.070.22 Fan Isolator Switch, 3 Pole	WHI		SC/CP
922.071.22 I Gang Architrave Switch, 86x37mm	WHI	WHI	SC/CP
922.081.22 I Gang Architrave Switch, 86x37mm	CP	WHI	SC/CP
		\neg	
	$ \Box$	ا ا	
	0	∃"	
922.099.22.01 Gang Speaker Outlet		WHI	SC/CP
722.077.22.01 1 Gang Speaker Outlet		4 4 111	30/01

922.234.22

922.235.22

922.236.22

I Gang Satellite Socket

TV + FM + Satellite Outlet

TV + Satellite Socket

922.245.22.01 | Gang Data Socket, RJ45(Cat5)

922.245.22.02 2 Gang Data Socket, RJ45(Cat5)

Also Available:

WHI

SC/CP

SC/CP

SC/CP

SC/CP WHI SC/CP




922.011.31 (Shown Actual Size)






922.002.31



922.004.31



922.013.31




922.041.31



922.022.31



922.024.31



922.032.31



922.034.31




922.040.31



922.038.31



922.061.31



922.092.31



922.063.31



922.065.31



922.091.31




922.235.31




Material	Small Plate	Large Plate	Interior
Die Cast Brass	92 x 92mm	150 x 92mm	Crabtree White

INTERCHANGEABLE GRID SWITCHES (PLASTIC ROCKER)				
922.001.31	I Gang Switch 2 Way	WHI	WHI	SB/PB
922.002.31	2 Gang Switch 2 Way	WHI	WHI	SB/PB
922.003.31	3 Gang Switch 2 Way	WHI	WHI	SB/PB
922.004.31	4 Gang Switch 2 Way	WHI	WHI	SB/PB
922.005.31	Spur Fused with Switch	WHI	WHI	SB/PB
922.006.31	Spur Fused with Switch & Cord Outlet	WHI	WHI	SB/PB
922.007.31	Spur Fused with Neon	WHI	WHI	SB/PB
922.008.31	Spur Fused with Neon & Cord Outlet	WHI	WHI	SB/PB
922.009.31	I Gang Switch: Intermediate	WHI	WHI	SB/PB
	•			

INTERCHAN	INTERCHANGEABLE GRID SWITCHES (METAL ROCKER)				
922.011.31	I Gang Switch 2 Way	PB	WHI	SB/PB	
922.012.31	2 Gang Switch 2 Way	PB	WHI	SB/PB	
922.013.31	3 Gang Switch 2 Way	PB	WHI	SB/PB	
922.014.31	4 Gang Switch 2 Way	PB	WHI	SB/PB	
922.015.31	Spur Fused with Switch	PB	WHI	SB/PB	
922.017.31	Spur Fused with Neon	PB	WHI	SB/PB	
922.019.31	I Gang Switch: Intermediate	PB	WHI	SB/PB	
922.020.31	I Gang Switch, 20amp Double-Pole	PB	WHI	SB/PB	
	•				



922.021.31	I Gang Dimmer Switch 400 Watts 2 Way	SB/PB
922.022.31	2 Gang Dimmer Switch 400 Watts 2 Way	SB/PB
922.023.31	3 Gang Dimmer Switch 400 Watts 2 Way	SB/PB
922.024.31	4 Gang Dimmer Switch 400 Watts 2 Way	SB/PB
922.026.31	I Gang Dimmer Switch, 630 Watts 2 Way	SB/PB
922.027.31	2 Gang Dimmer Switch, 400 Watts on Large Plate 2 Way	SB/PB
922.028.31	I Gang Dimmer Switch 1000 Watts on Large Plate 2 Way	SB/PB



922.030.31	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SB/PB
922.031.31	13amp Single Socket	PB	WHI	SB/PB
922.032.31	13amp Double Socket	PB	WHI	SB/PB
922.033.31	2 amp Single Socket		WHI	SB/PB
922.034.31	5 amp Single Socket		WHI	SB/PB
922.091.31	13amp Single Socket	WHI	WHI	SB/PB
922.092.31	13amp Double Socket	WHI	WHI	SB/PB

922 Series: SATIN BRASS / POLISHED BRASS

Code	Description Rocker	r Trim	Plate
0 0 0 0			
022 025 21	TV Ovelet leelend	WHI	CD/DD
922.035.31 922.035.31.NI	TV Outlet, Isolated TV Outlet, Non Isolated	WHI	SB/PB SB/PB
922.035.31.10	TV/FM Outlet, Isolated	WHI	SB/PB
922.036.31.NI		WHI	SB/PB
922.037.31	Telecom Outlet, Master	WHI	SB/PB
922.038.31	Telecom Outlet, Slave	WHI	SB/PB
922.039.31	Cord Outlet, Grommet on Plate	WHI	SB/PB
922.047.31	Twin-Telecom, Master	WHI	SB/PB
922.048.31	Twin-Telecom, Slave	WHI	SB/PB
	. , , , , , , , , , , , , , , , , , , ,		
			0
ا چًا			
			Д Д 115V 235V В В
0		169	
922.040.31	Cooker Switch 45amp D/P with Neon RED) WHI	SB/PB
922.040.31.SP	45amp Double-Pole Switch with Neon RED) WHI	SB/PB
922.041.31	Blanking Plate Single		SB/PB
922.042.31	Blanking Plate Double		SB/PB
922.046.31	Cooker Switch 45amp with 13amp Socket RED) WHI	SB/PB
922.050.31	Shaver Socket	WHI	SB/PB
			7
			0
922.061.31	I Gang Moulded Rocker Switch 2 Way WH		SB/PB
922.062.31	2 Gang Moulded Rocker Switch 2 Way WH	l	SB/PB
922.063.31	3 Gang Moulded Rocker Switch 2 Way WH	l	SB/PB
922.064.31	4 Gang Moulded Rocker Switch 2 Way WH		SB/PB
922.065.31	Spur Fused with Switch WH		SB/PB
922.069.31	I Gang Moulded Rocker Switch: Intermediate W	/HI	SB/PB
[,			
	8		
922.070.31	Fan Isolator Switch, 3 Pole WH		SB/PB
922.071.31	I Gang Architrave Switch, 86x37mm WH		SB/PB
922.081.31	I Gang Architrave Switch, 86x37mm PE	3 WHI	SB/PB
		$\overline{}$	
		\Box_{\bullet}	
° @ ° °			

922.099.31.01 | Gang Speaker Outlet

I Gang Satellite Socket

TV + FM + Satellite Outlet

TV + Satellite Socket

922.245.31.01 | Gang Data Socket, RJ45(Cat5)

922.245.31.02 2 Gang Data Socket, RJ45(Cat5)

922.234.31

922.235.31

922.236.31

Also Available:

WHI

WHI

WHI

SB/PB

SB/PB


SB/PB

SB/PB

SB/PB

SB/PB

916 Series: FLOOR SOCKETS WITH HINGED COVER



916.032.20 (Shown Actual Size)



	916 Series: POLISHED BRASS				
Code	Description	Size	Trim	Plate	
916.031.10	13amp Single Socket, Un-Switched	85 x 93	WHI	PB	
916.032.10	13amp Double Socket, Un-Switched	85 x 146	WHI	PB	
916.033.10	2 amp Single Socket	85 x 93	WHI	PB	
916.034.10	5 amp Single Socket	85 x 93	WHI	PB	
916.035.10	TV Outlet	85 x 93	WHI	PB	
916.036.10	TV/FM Outlet	85 x 93	WHI	PB	
916.037.10	Telecom Outlet, Master	85 x 93	WHI	PB	
916.038.10	Telecom Outlet, Slave	85 x 93	WHI	PB	

	916 Series: POLISHED CHROME				
Code	Description	Size	Trim	Plate	
916.031.20	13amp Single Socket, Un-Switched	85 x 93	WHI	CP	
916.032.20	13amp Double Socket, Un-Switched	85 x 146	WHI	CP	
916.033.20	2 amp Single Socket	85 x 93	WHI	CP	
916.034.20	5 amp Single Socket	85 x 93	WHI	CP	
916.035.20	TV Outlet	85 x 93	WHI	CP	
916.036.20	TV/FM Outlet	85 x 93	WHI	CP	
916.037.20	Telecom Outlet, Master	85 x 93	WHI	CP	
916.038.20	Telecom Outlet, Slave	85 x 93	WHI	CP	

	916 Series: SATIN CHROME				
Code	Description	Size	Trim	Plate	
916.031.21	13amp Single Socket, Un-Switched	85 x 93	WHI	SCP	
916.032.21	13amp Double Socket, Un-Switched	85 x 146	WHI	SCP	
916.033.21	2 amp Single Socket	85 x 93	WHI	SCP	
916.034.21	5 amp Single Socket	85 x 93	WHI	SCP	
916.035.21	TV Outlet	85 x 93	WHI	SCP	
916.036.21	TV/FM Outlet	85 x 93	WHI	SCP	
916.037.21	Telecom Outlet, Master	85 x 93	WHI	SCP	
916.038.21	Telecom Outlet, Slave	85 x 93	WHI	SCP	

930 Series: CEILING SWITCHES





930.010.20







930.060.20

930.060.89



930.065.00.06



930.062.89

930.067.20 CHROME CORD WEIGHT



930.067.89 **ANTIQUE GOLD** CORD WEIGHT (Sold Separately)



930.065.00.05


930.062.20





	930 Series: POLISHED BRASS		
Code	Description	Materia	Finish
930.010.10	Pull Cord Switch, 6amp 2way	Plastic	PB
930.010.20	Pull Cord Switch, 6amp 2way	Plastic	CP
930.060.20	Pull Cord Switch, 6amp 2way, with Metal Knob	Brass	CP
930.060.89	Pull Cord Switch, 6amp 2way, with Metal Knob	Brass	ANTGO
930.062.20	Pull Cord Switch, 6amp 2way, with Metal Knob	Brass	CP
930.062.89	Pull Cord Switch, 6amp 2way, with Metal Knob	Brass	ANTGO
930.065.00.05	Round Patteress Only	Wood	Pine
930.065.00.06	Round Patteress Only	Wood	Mahogany
930.066.60	Round Patteress Only	Ceramic	White
930.067.20	Cord Weight Pull Knob Only	Brass	СР
930.067.89	Cord Weight Pull Knob Only	Brass	ANTGO





914.011.10 914.032.10

914 Series: POLISHED BRASS

Code Description Rocker Trim Plate				
914.011.10	Code Description	Rocker	Trim	Plate
914.011.10				
914.011.10][]•		
914.011.10				
914.012.10 2 Gang Switch, 2 Way PB BLK PB 914.013.10 3 Gang Switch, 2 Way PB BLK PB 914.014.10 4 Gang Switch, 2 Way PB BLK PB 914.015.10 Spur Fused with Switch PB BLK PB 914.016.10 Spur Fused with Switch & Cord Outlet PB BLK PB 914.017.10 Spur Fused with Neon PB BLK PB 914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB PB <t< td=""><td></td><td>0</td><td></td><td></td></t<>		0		
914.012.10 2 Gang Switch, 2 Way PB BLK PB 914.013.10 3 Gang Switch, 2 Way PB BLK PB 914.014.10 4 Gang Switch, 2 Way PB BLK PB 914.015.10 Spur Fused with Switch PB BLK PB 914.016.10 Spur Fused with Switch & Cord Outlet PB BLK PB 914.017.10 Spur Fused with Neon PB BLK PB 914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB	914.011.10	PB	BLK	PB
914.014.10 4 Gang Switch, 2 Way PB BLK PB 914.015.10 Spur Fused with Switch PB BLK PB 914.016.10 Spur Fused with Switch & Cord Outlet PB BLK PB 914.017.10 Spur Fused with Neon PB BLK PB 914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.020.10 I Gang Dimmer Switch 400 Watts, 2 Way PB 914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 400 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.031.10 I 3amp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I 3amp Single Socket PB BLK PB	<u> </u>	PB	BLK	PB
914.015.10 Spur Fused with Switch PB BLK PB 914.016.10 Spur Fused with Switch & Cord Outlet PB BLK PB 914.017.10 Spur Fused with Neon PB BLK PB 914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.020.10 I Gang Switch 400 Watts, 2 Way PB 914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 400 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 I Samp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Samp Single Socket PB BLK PB	914.013.10 3 Gang Switch, 2 Way	PB	BLK	PB
914.016.10 Spur Fused with Switch & Cord Outlet PB BLK PB 914.017.10 Spur Fused with Neon PB BLK PB 914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.021.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.021.10 I Gang Dimmer Switch 400 Watts, 2 Way PB 914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 630 Watts, 2 Way PB 914.028.10 I Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 I Samp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Samp Single Socket PB BLK PB	914.014.10 4 Gang Switch, 2 Way	PB	BLK	PB
914.017.10 Spur Fused with Neon PB BLK PB 914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB OUTLING PB BLK PB	914.015.10 Spur Fused with Switch	PB	BLK	PB
914.018.10 Spur Fused with Neon & Cord Outlet PB BLK PB 914.019.10 I Gang Switch, Intermediate PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB 914.020.10 I Gang Switch, 20amp Double-Pole PB BLK PB	914.016.10 Spur Fused with Switch & Cord Outle	et PB	BLK	PB
914.019.10 Gang Switch, Intermediate PB BLK PB 914.020.10 Gang Switch, 20amp Double-Pole PB BLK PB 914.021.10 Gang Dimmer Switch 400 Watts, 2 Way PB 914.021.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 1 Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 1 Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 13amp Fuse-Only on 1 Gang Plate BLK BLK PB 914.031.10 13amp Single Socket PB BLK PB 914.031.10 13amp Single Socket PB BLK PB 914.031.10 914.	914.017.10 Spur Fused with Neon	PB	BLK	PB
914.020.10 Gang Switch, 20amp Double-Pole PB BLK PB 914.021.10 I Gang Dimmer Switch 400 Watts, 2 Way PB 914.021.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 1 Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 1 Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 13amp Fuse-Only on 1 Gang Plate BLK BLK PB 914.031.10 13amp Single Socket PB BLK PB 914.031.10 13amp Single Socket PB BLK PB 914.031.10 PB 914.031.10 PB 914.031.10 PB 914.031.10 PB 914.031.10 914.031.10 PB 914.031.10				
914.021.10				
914.021.10	914.020.10 I Gang Switch, 20amp Double-Pole	PB	BLK	PB
914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 14.030.10 I Jamp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Jamp Single Socket PB BLK PB			AllABLE Low litage	
914.022.10 2 Gang Dimmer Switch 400 Watts, 2 Way PB 914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 14.030.10 I Jamp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Jamp Single Socket PB BLK PB	914.021.10	Wav		PB
914.023.10 3 Gang Dimmer Switch 400 Watts, 2 Way PB 914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 13amp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 13amp Single Socket PB BLK PB				
914.024.10 4 Gang Dimmer Switch 400 Watts, 2 Way PB 914.026.10 I Gang Dimmer Switch 630 Watts, 2 Way PB 914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 I Jamp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Jamp Single Socket PB BLK PB				PB
914.027.10 2 Gang Dimmer Switch 400 Watts on Large Plate, 2 Way PB 914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 I Jamp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Jamp Single Socket PB BLK PB				
914.028.10 I Gang Dimmer Switch 1000 Watts on Large Plate, 2 Way PB 914.030.10 I Jamp Fuse-Only on I Gang Plate BLK BLK PB 914.031.10 I Jamp Single Socket PB BLK PB				
914.030.10 13amp Fuse-Only on 1 Gang Plate BLK BLK PB 914.031.10 13amp Single Socket PB BLK PB	914.027.10 2 Gang Dimmer Switch 400 Watts on	Large Plate,	2 Way	PB
914.030.10 13amp Fuse-Only on 1 Gang Plate BLK BLK PB 914.031.10 13amp Single Socket PB BLK PB	914.028.10 I Gang Dimmer Switch 1000 Watts o	n Large Plate	,2 Way	PB
914.031.10 13amp Single Socket PB BLK PB		· 60°		
914.031.10 13amp Single Socket PB BLK PB	914.030.10 I 3amp Fuse-Only on I Gang Plate	BLK	BLK	PB
		PB	BLK	PB
	914.032.10 I3amp Double Socket	PB	BLK	PB


BLK

BLK

РΒ

PB

Material	Small Plate	Large Plate	Interior
Forged Brass	93 x 93mm	146 x 93mm	Wandsworth



2 amp Single Socket

5 amp Single Socket

914.033.10

914.034.10





915.032.21 915.011.21

Material	Small Plate	Large Plate	Interior
Forged Brass	93 x 93mm	146 x 93mm	Wandsworth

Torged Brass 75 X 75mm Tro X 75mm	- vvarius	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
Code Description	Rocker	Trim	Plate
	$\overline{}$		
	n l		
	∐°		
	9		
	CCD	\ A /I II	
915.011.21 Gang Switch, 2 Way	SCP	WHI	SCP
915.012.21 2 Gang Switch, 2 Way	SCP	WHI	SCP
915.013.21 3 Gang Switch, 2 Way	SCP SCP	WHI	SCP SCP
915.014.21 4 Gang Switch, 2 Way 915.015.21 Spur Fused with Switch	SCP	WHI	SCP
915.016.21 Spur Fused with Switch & Cord Outlet		WHI	SCP
915.017.21 Spur Fused with Neon	SCP	WHI	SCP
915.018.21 Spur Fused with Neon & Cord Outlet	SCP	WHI	SCP
915.019.21 I Gang Switch, Intermediate	SCP	WHI	SCP
915.020.21 I Gang Switch, 20amp Double-Pole	SCP	WHI	SCP
		ALSO AILABLE Low oltage	
		Low oltage	
915.021.21	/ay		SCP
915.022.21 2 Gang Dimmer Switch 400 Watts, 2 W			SCP
915.023.21 3 Gang Dimmer Switch 400 Watts, 2 W	/ay		SCP
915.024.21 4 Gang Dimmer Switch 400 Watts, 2 W	/ay		SCP
915.026.21 I Gang Dimmer Switch 630 Watts, 2 W			SCP
915.027.21 2 Gang Dimmer Switch 400 Watts on L			SCP
915.028.21 I Gang Dimmer Switch 1000 Watts on	Large Plate	,2 Way	SCP
		\ A /I I'	
915.030.21 13amp Fuse-Only on 1 Gang Plate	WHI	WHI	SCP
915.031.21 13amp Single Socket	SCP	WHI	SCP
915.032.21 13amp Double Socket	SCP	WHI	SCP

WHI

WHI

SCP

SCP

915.033.21

915.034.21

2 amp Single Socket

5 amp Single Socket

915 Series: SATIN CHROME

Code Description	Rocker	Trim	Plate
915.035.21 TV Outlet, Isolated		WHI	SCP
915.035.21.NI TV Outlet, Non Isolated			SCP
915.036.21 TV/FM Outlet, Isolated		WHI	SCP
915.036.21.NI TV/FM Outlet Non-Isolated			SCP
915.037.21 Telecom Outlet, Master		WHI	SCP
915.038.21 Telecom Outlet, Slave		WHI	SCP
915.039.21 Cord Outlet, Grommet on Plate		WHI	SCP
915.047.21 Twin-Telecom, Master		WHI	SCP
915.048.21 Twin-Telecom, Slave		WHI	SCP
915.040.21 Cooker Switch 45amp D/P with Neon	WHI	WHI	SCP
915.041.21 Blanking Plate Single	*****	******	SCP
915.042.21 Blanking Plate Double			SCP
915.050.21 Shaver Socket		WHI	SCP
9 99 999	?	9	
915.051.21	SCP		SCP
915.052.21 2 Gang Dolly Switch, 2 Way	SCP		SCP
915.053.21 3 Gang Dolly Switch, 2 Way	SCP		SCP
915.054.21 4 Gang Dolly Switch, 2 Way	SCP		SCP
915.059.21 I Gang Dolly Switch, Intermediate	SCP		SCP
	•		
915.099.21.01 Gang Speaker Outlet		WHI	SCP
915.234.21 I Gang Satellite Socket			SCP
915.235.21 TV + Satellite Socket			SCP
915.236.21 TV + FM + Satellite Outlet			SCP
915.245.21.01 IGang Data Socket,RJ45(Cat5)		WHI	SCP
915.245.21.02 2Gang Data Socket,RJ45(Cat5)		WHI	SCP





Small Plate

95 x 95mm

Large Plate

155 x 95mm

Interior

Crabtree

918.011.10

918.032.10

Material

Forged Brass

918 Series: POLISHED BRASS

Code Description Roo	ker	Trim	Plate
918.011.10	PB	WHI	PB
918.012.10 2 Gang Switch 2 Way	PB	WHI	PB
918.013.10 3 Gang Switch 2 Way	PB	WHI	PB
918.014.10 4 Gang Switch 2 Way	PB	WHI	PB
918.015.10 Spur Fused with Switch	PB	WHI	PB
918.016.10 Spur Fused with Switch & Cord Outlet	PB	WHI	PB
918.017.10 Spur Fused with Neon	PB	WHI	PB
918.018.10 Spur Fused with Neon & Cord Outlet	PB	WHI	PB
918.019.10 I Gang Switch: Intermediate	PB	WHI	PB
918.020.10 I Gang Switch 20amp Double-Pole	PB	WHI	PB
	AV. I	ALSO AILABLE LOW Ditage	
918.021.10 I Gang Dimmer Switch 400 Watts 2 Way			PB
918.022.10 2 Gang Dimmer Switch 400 Watts 2 Way			PB
918.023.10 3 Gang Dimmer Switch 400 Watts 2 Way			PB
918.024.10 4 Gang Dimmer Switch 400 Watts 2 Way			PB
918.026.10 I Gang Dimmer Switch 630 Watts 2 Way			PB
918.027.10 2 Gang Dimmer Switch 400 Watts on Large	Plate	2 Way	PB
918.028.10 I Gang Dimmer Switch 1000 Watts 2 Way			PB
	_		
)		

C-1-	Description		Dl	Tulina	Dista
Code	Description		Rocker	Trim	Plate
● ● ●					
918.035.10	TV Outlet, Isolated			WHI	PB
918.035.10.NI	TV Outlet, Non-Isolat	ted		WHI	PB
918.036.10	TV/FM Outlet, Isolate	d		WHI	PB
918.036.10.NI	TV/FM Outlet, Non-Is	solated		WHI	PB
918.037.10	Telecom Outlet, Mast	er		WHI	PB
918.038.10	Telecom Outlet, Slave			WHI	PB
918.039.10	Cord Outlet, Gromm			WHI	PB
918.047.10	Twin-Telecom, Maste	r		WHI	PB
918.048.10	Twin-Telecom, Slave			WHI	PB
	8		§ [4]	Ø	
918.040.10	Cooker Switch 50amp	D/P with Neon	WHI	WHI	PB
918.041.10	Blanking Plate Single				PB
918.042.10	Blanking Plate Double				PB
918.046.10	Cooker Switch with I	3amp Socket	WHI	WHI	PB
918.050.10	Shaver Socket			WHI	PB
918.070.10	Fan Isolator Switch, 3		WHI	WHI	PB
918.081.10	I Gang Architrave Sw	ritch, 81x37mm	PB	WHI	PB
· • •	• • • • • • • • • • • • • • • • • • •				
918.099.10.01	I Gang Speaker Outle			WHI	PB
918.234.10	I Gang Satellite Socke	et			PB
918.235.10	TV + Satellite Socket				PB
918.236.10	TV + FM + Satellite C				PB
918.245.10.01	I Gang Data Socket, I			WHI	PB
918.245.10.02	2 Gang Data Socket, I	RJ45(Cat5)		WHI	PB

13amp Single Socket

2 amp Single Socket

5 amp Single Socket

13amp Double Socket

13amp Fuse-Only on 1 Gang Plate

WHI

РВ

WHI

WHI

WHI

WHI

WHI

PB

PB

PB

PB

РВ

918.030.10

918.031.10

918.032.10

918.033.10

918.034.10





919.032.10 919.012.10

Material	Small Plate	Large Plate	Interior
Forged Brass	93 x 93mm	155 x 93mm	Crabtree


Code Description Roo	ker	Trim	Plate
919.011.10	PB	WHI	PB
919.012.10 2 Gang Switch 2 Way	PB	WHI	PB
919.013.10 3 Gang Switch 2 Way	PB	WHI	PB
919.014.10 4 Gang Switch 2 Way	PB	WHI	PB
919.015.10 Spur Fused with Switch	PB	WHI	PB
919.016.10 Spur Fused with Switch & Cord Outlet	PB	WHI	PB
919.017.10 Spur Fused with Neon	PB	WHI	PB
919.018.10 Spur Fused with Neon & Cord Outlet	PB	WHI	PB
919.019.10 I Gang Switch: Intermediate	PB	WHI	PB
919.020.10 I Gang Switch, 20amp Double-Pole	PB	WHI	PB
	Av.	ALSO AILABLE Low Pitage	
919.021.10 I Gang Dimmer Switch 400 Watts 2 Way			PB
919.022.10 2 Gang Dimmer Switch 400 Watts 2 Way			PB
919.023.10 3 Gang Dimmer Switch 400 Watts 2 Way			PB
919.024.10 4 Gang Dimmer Switch 400 Watts 2 Way			PB
919.026.10 I Gang Dimmer Switch 630 Watts 2 Way			PB
919.027.10 2 Gang Dimmer Switch 400 Watts on Large	Plate 2	2 Way	PB
919.028.10 I Gang Dimmer Switch 1000 Watts 2 Way			PB

919.030.10 13amp Fuse-Only on 1 Gang Plate WHI WHI PB 919.031.10 13amp Single Socket PB WHI PB 919.032.10 13amp Double Socket PB WHI PB 919.033.10 2 amp Single Socket WHI PB 919.034.10 5 amp Single Socket WHI PB					
919.032.10 13amp Double Socket PB WHI PB 919.033.10 2 amp Single Socket WHI PB	919.030.10	13amp Fuse-Only on 1 Gang Plate	WHI	WHI	PB
919.033.10 2 amp Single Socket WHI PB	919.031.10	13amp Single Socket	PB	WHI	PB
	919.032.10	13amp Double Socket	PB	WHI	PB
919.034.10 5 amp Single Socket WHI PB	919.033.10	2 amp Single Socket		WHI	PB
	919.034.10	5 amp Single Socket		WHI	PB

919 Series: POLISHED BRASS

Code	Description	Rocker	Trim	Plate
● ● ∘		•		
919.035.10	TV Outlet, Isolated		WHI	PB
919.035.10.NI	TV Outlet, Non-Isolated		WHI	PB
919.036.10	TV/FM Outlet, Isolated		WHI	PB
919.036.10.NI			WHI	PB
919.037.10	Telecom Outlet, Master		WHI	PB
919.038.10	Telecom Outlet, Slave		WHI	PB
919.039.10	Cord Outlet, Grommet on Plate		WHI	PB
919.047.10	Twin-Telecom, Master		WHI	PB
919.048.10	Twin-Telecom, Slave		WHI	PB
			Ø 235V	
919.040.10	Cooker Switch 50amp D/P with Neon	WHI	WHI	PB
919.041.10	Blanking Plate Single			PB
919.042.10	Blanking Plate Double			PB
919.046.10	Cooker Switch with 13amp Socket	WHI	WHI	PB
919.050.10	Shaver Socket		WHI	PB
919.070.10	Fan Isolator Switch, 3 Pole	WHI	WHI	PB
919.081.10	I Gang Architrave Switch, 81x37mm	PB	WHI	PB
· • •		•	•	
919.099.10.01	I Gang Speaker Outlet		WHI	PB
919.234.10	I Gang Satellite Socket			PB
919.235.10	TV + Satellite Socket			PB
919.236.10	TV + FM + Satellite Outlet			PB
919.245.10.01	, , , ,		WHI	PB
919.245.10.02	2 Gang Data Socket,RJ45(Cat5)		WHI	PB





924.051.10 924.032.10

924 Series: POLISHED BRASS

Code Description	Rocker	Trim	Plate
	9		
924.011.10	PB	WHI	PB
924.012.10 2 Gang Switch 2 Way	PB	WHI	PB
924.013.10 3 Gang Switch 2 Way	PB	WHI	PB
924.014.10 4 Gang Switch 2 Way	PB	WHI	PB
924.015.10 Spur Fused with Switch	PB	WHI	PB
924.016.10 Spur Fused with Switch & Cord Outlet	PB	WHI	PB
924.017.10 Spur Fused with Neon	PB	WHI	PB
924.018.10 Spur Fused with Neon & Cord Outlet	PB	WHI	PB
924.019.10 I Gang Switch: Intermediate	PB	WHI	PB
924.020.10 I Gang Switch, 20amp Double-Pole	PB	WHI	PB
		ALSO AILABLE Low Iltage	
924.021.10 I Gang Dimmer Switch 400 Watts 2 Way	,		PB
924.022.10 2 Gang Dimmer Switch 400 Watts 2 Way	,		PB
924.023.10 3 Gang Dimmer Switch 400 Watts 2 Way	,		PB
924.024.10 4 Gang Dimmer Switch 400 Watts 2 Way	,		PB
924.026.10 I Gang Dimmer Switch 630 Watts 2 Way			PB
924.027.10 2 Gang Dimmer Switch 400 Watts on Lar	ge Plate 2	2 Way	PB
924.028.10 I Gang Dimmer Switch 1000 Watts 2 Wa	ay		PB
924.030.10 I3amp Fuse-Only on I Gang Plate	WHI	WHI	PB
924.031.10	PB	WHI	PB
924.032.10 I3amp Double Socket	PB	WHI	PB


WHI

WHI

РΒ

PB

Material	Small Plate	Large Plate	Interior
Forged Brass	95 x 95mm	150 x 95mm	Crabtree White



2 amp Single Socket

5 amp Single Socket

924.033.10

924.034.10



924.011.20



924.031.20


Material	Small Plate	Large Plate	Interior
Forged Brass	95 x 95mm	150 x 95mm	Crabtree White

Code Description Ro	cker	Trim	Plate
924.011.20 Gang Switch 2 Way	СР	WHI	СР
924.012.20 2 Gang Switch 2 Way	СР	WHI	СР
924.013.20 3 Gang Switch 2 Way	CP	WHI	CP
924.014.20 4 Gang Switch 2 Way	CP	WHI	CP
924.015.20 Spur Fused with Switch	CP	WHI	CP
924.016.20 Spur Fused with Switch & Cord Outlet	CP	WHI	CP
924.017.20 Spur Fused with Neon	CP	WHI	CP
924.018.20 Spur Fused with Neon & Cord Outlet	CP	WHI	CP
924.019.20 I Gang Switch: Intermediate	CP	WHI	CP
924.020.20 I Gang Switch, 20amp Double-Pole	CP	WHI	<u>CP</u>
		ALSO AILABLE LOW Ditage	
924.021.20 Gang Dimmer Switch 400 Watts 2 Way			СР
924.021.20 I Gang Dimmer Switch 400 Watts 2 Way 924.022.20 2 Gang Dimmer Switch 400 Watts 2 Way			CP
924.023.20 3 Gang Dimmer Switch 400 Watts 2 Way			CP
924.024.20 4 Gang Dimmer Switch 400 Watts 2 Way			CP
924.026.20 I Gang Dimmer Switch 630 Watts 2 Way			СР
924.027.20 2 Gang Dimmer Switch 400 Watts on Large	Plate 2	2 Way	СР
924.028.20 I Gang Dimmer Switch 1000 Watts 2 Way			CP
	a		
			
	WHI	WHI	СР
924.030.20 13amp Fuse-Only on 1 Gang Plate		WHI WHI	CP CP
924.030.20 13amp Fuse-Only on 1 Gang Plate	WHI		
924.030.20 13amp Fuse-Only on 1 Gang Plate 924.031.20 13amp Single Socket	WHI CP	WHI	СР

924 Series: POLISHED CHROME

Cod	de			De	scri	ptic	n									Roc	ker		Tri	m	Plate
0	•	0	6	••	0 0	6		0	0	0	0		<u>-</u>		•						
924	.03	5.2	0	TV	Ou	tlet,	Isol	ated	<u> </u>										WI	ΗΙ	СР
924	.03	6.2	0	ΤV	/FM	Ou	tlet,	Isol	ated	1									WI	ΗΙ	CP
924	.03	7.2	0	Te	leco	m C	Outle	et, M	1aste	er									WI	HI	CP
924	.03	8.2	0				Dutle	-											WI		CP
924			_				et, (n Pla	ate	9						WI		CP
924							com			•									WI		CP
924	.04	8.2	0	Tw	⁄in-1	Tele	com	, Sla	ve										WI	<u> </u>	<u>CP</u>
	•		6	į	· •	0		8	0				8		6						Ø
924	Ω4	0.2	n	<u></u>	oko	r Sw	vitch	45	amp	D/F) w/i	th	Neo	'n		_	۷HI		WI	-11	CP
924													Nec				RED		WI		CP
924					_		ate :			*****	. ,,,		. 100	,,,						-	CP
924							ate														CP
924	.04	6.2	0				vitch			3am	p So	ocl	ket			\	۷НІ		WI	ΗΙ	СР
924	.05	0.2	0			Soc					•								WI	ΗΙ	CP
	P			ବୃ ବୃ			9	@	ģ			Q	9 @ (P	ନୃ			Q	•		
924	.05	1.2	0	10	Sang	g Do	lly S	wite	ch 2	Wa	ıy						CP				CP
924	.05	2.2	0	2 (Sang	g Do	lly S	wite	ch 2	Wa	ıy						CP				CP CP
924	.05	3.2	0				lly S										CP				CP CP
924	_	_	_				lly S										CP				CP
924	.05	9.2	0	1 (Sang	g Do	lly S	wite	ch: I	nter	me	dia	ite				CP				CP
<u></u>	_]•	0	•	0	0 (• •) 0	0 (• •	0 0		• 🗀		0						
924	.07	0.2	0	Far	lsc	lato	r Sv	vitch	n, 3	Pole						_\	٧HI				CP
924	.23	4.2	0	10	ang	Sat	ellite	e So	cke	t											CP
924	.23	5.2	0				lite S														СР
924							Sat														CP
924	.24	5.2	0.0	10	Sang	g Da	ta So	ocke	et, R	J45(Cat	:5)							WI	H	CP





WHI

WHI

WHI

WHI

WHI

WHI

PB

PB

РВ

PB

Material

1.5mm Brass Sheet



Small Plate

86x86mm

Large Plate

146x86mm

Interior

MEM

926 Series: POLISHED BRASS

Code	Description	Rocker	Trim	Plate
		٦		
0 0		6		
926.061.10	I Gang Moulded Rocker Switch, 2 Way	WHI		PB
926.062.10	2 Gang Moulded Rocker Switch, 2 Way	WHI		PB
926.063.10	3 Gang Moulded Rocker Switch, 2 Way	WHI		PB
926.064.10	4 Gang Moulded Rocker Switch, 2 Way	WHI		PB
926.065.10	Spur Fused with Switch	WHI		PB
926.066.10	Spur Fused with Switch & Cord Outlet	WHI		PB
926.067.10	Spur Fused with Neon	WHI		PB
926.069.10	I Gang Moulded Rocker Switch: Interm			PB
926.070.10	Fan Isolator Switch, 3 Pole	WHI		PB
		O ®	LSO ILABLE ow tage	
926.021.10	L Cana Dimmon Suiteh 400 Water 2 W	lov		PB
926.021.10	I Gang Dimmer Switch 400 Watts, 2 W 2 Gang Dimmer Switch 400 Watts, 2 W			PB
926.023.10	3 Gang Dimmer Switch 400 Watts, 2 W			PB
926.024.10	4 Gang Dimmer Switch 400 Watts, 2 W			PB
926.026.10	I Gang Dimmer Switch 630 Watts, 2 W			PB
926.027.10	2 Gang Dimmer Switch 400 Watts on L		Wav	PB
926.028.10	I Gang Dimmer Switch 1000 Watts, 2 \		,,	PB
		,		

1.5iiiii Diass	Julicet 00x0011		1400001111	··		
Code	Description			Rocker	Trim	Plate
· • •	●● •	•				
926.035.10	TV Outlet, Isolated				WHI	PB
926.035.10.NI	TV Outlet, Non Isol	ated			WHI	PB
926.036.10	TV/FM Outlet, Isola	ted			WHI	PB
926.036.10.NI	TV/FM Outlet Non-	Isolated			WHI	PB
926.037.10	Telecom Outlet, Ma	ster			WHI	PB
926.038.10	Telecom Outlet, Sla	ve			WHI	PB
926.047.10	Twin-Telecom, Mass	ter			WHI	PB
926.048.10	Twin-Telecom, Slave	е			WHI	PB
	•	8	Δ Ω 115V 255V Φ Φ			
926.040.10	Cooker Switch 45ar	np D/P wi	th Neon	WHI	WHI	PB
926.041.10	Blanking Plate Single					PB
926.042.10	Blanking Plate Doub	le				PB
926.050.10	Shaver Socket				WHI	PB
© (a) o	⊙ ∘⊙ ⊙ ∘	⊙ ⊙ ∘	• 🔲 •			
926.099.10.01	I Gang Speaker Out	tlet			BLK	PB
926.234.10	I Gang Satellite Soc					PB
926.235.10	TV + Satellite Socke	t				PB
926.236.10	TV + FM + Satellite	Outlet				PB
926.245.10.01	I Gang Data Socket,	RJ45(Cat5	5)		WHI	PB

13amp Single Socket

5 amp Single Socket

13amp Double Socket


13amp Fuse-Only on 1 Gang Plate

926.030.10

926.031.10

926.032.10

926.034.10





926.032.53 926.063.53

BLK

BLK

BLK

BLK

BLK

IBMA

IBMA

IBMA

Material	Small Plate	Large Plate	Interior
I.5mm Brass Sheet	86x86mm	146x86mm	MEM

Rocker Trim Plate Code **Description** 926.061.53 I Gang Moulded Rocker Switch, 2 Way IBMA BLK 926.062.53 2 Gang Moulded Rocker Switch, 2 Way **BLK IBMA** 926.063.53 3 Gang Moulded Rocker Switch, 2 Way **BLK IBMA** 926.06<u>4</u>.53 IBMA 4 Gang Moulded Rocker Switch, 2 Way **BLK** 926.065.53 IBMA Spur Fused with Switch **BLK** 926.066.53 Spur Fused with Switch & Cord Outlet **BLK IBMA** 926.067.53 Spur Fused with Neon BLK **IBMA** 926.069.53 I Gang Moulded Rocker Switch: Intermediate BLK IBMA IBMA 926.070.53 Fan Isolator Switch, 3 Pole **BLK** 0000 926.021.53 I Gang Dimmer Switch 400 Watts, 2 Way **IBMA** IBMA 926.022.53 2 Gang Dimmer Switch 400 Watts, 2 Way 3 Gang Dimmer Switch 400 Watts, 2 Way 926.023.53 **IBMA** 926.024.53 4 Gang Dimmer Switch 400 Watts, 2 Way IBMA 926.026.53 I Gang Dimmer Switch 630 Watts, 2 Way **IBMA** 926.027.53 2 Gang Dimmer Switch 400 Watts on Large Plate, 2Way **IBMA** 926.028.53 I Gang Dimmer Switch 1000 Watts, 2 Way IBMA F U S E 926.030.53 13amp Fuse-Only on 1 Gang Plate BLK IBMA

926.031.53

926.032.53

926.034.53

13amp Single Socket


5 amp Single Socket

13amp Double Socket

926 Series: IMITATION BRONZE ANTIQUE

926.035.53 TV Outlet, Isolated 926.035.53.NI TV Outlet, Non Isolated 926.036.53 TV/FM Outlet, Isolated 926.036.53 TV/FM Outlet, Isolated 926.036.53.NI TV/FM Outlet Non-Isolated 926.037.53 Telecom Outlet, Master 926.038.53 Telecom Outlet, Slave 926.047.53 Twin-Telecom, Master 926.048.53 Twin-Telecom, Slave 926.048.53 Twin-Telecom, Slave 926.048.53 Twin-Telecom, Slave 926.048.53 Blanking Plate Single 926.041.53 Blanking Plate Double 926.050.53 Shaver Socket 926.050.53 Shaver Socket 926.050.53 Shaver Socket 926.050.53 Shaver Socket	Code	Description	Rocker	Trim	Plate
926.035.53.NI TV Outlet, Non Isolated 926.036.53 TV/FM Outlet, Isolated 926.036.53 NI TV/FM Outlet Non-Isolated 926.037.53 Telecom Outlet, Master 926.038.53 Telecom Outlet, Slave 926.047.53 Twin-Telecom, Master 926.048.53 Twin-Telecom, Slave 926.048.53 Twin-Telecom, Slave 926.040.53 Cooker Switch 45amp D/P with Neon BLK BLK IBMA 926.041.53 Blanking Plate Single 926.042.53 Blanking Plate Double 926.050.53 Shaver Socket BLK IBMA BLK IBMA 926.041.53 Blanking Plate Double BLK IBMA	o • o				
926.036.53 TV/FM Outlet, Isolated 926.036.53.NI TV/FM Outlet Non-Isolated 926.037.53 Telecom Outlet, Master 926.038.53 Telecom Outlet, Slave 926.047.53 Twin-Telecom, Master 926.048.53 Twin-Telecom, Slave 926.048.53 Cooker Switch 45amp D/P with Neon 926.041.53 Blanking Plate Single 926.042.53 Blanking Plate Double 926.050.53 Shaver Socket BLK IBMA BLK IBMA BLK IBMA BLK IBMA	926.035.53	TV Outlet, Isolated		BLK	IBMA
926.036.53.NI TV/FM Outlet Non-Isolated 926.037.53 Telecom Outlet, Master 926.038.53 Telecom Outlet, Slave 926.047.53 Twin-Telecom, Master 926.048.53 Twin-Telecom, Slave 926.048.53 Cooker Switch 45amp D/P with Neon 926.041.53 Blanking Plate Single 926.042.53 Blanking Plate Double 926.050.53 Shaver Socket BLK IBMA BLK IBMA BLK IBMA BLK IBMA	926.035.53.NI	TV Outlet, Non Isolated		BLK	IBMA
926.040.53 Cooker Switch 45amp D/P with Neon BLK IBMA 926.041.53 Blanking Plate Double 926.042.53 Shaver Socket BLK IBMA	926.036.53	TV/FM Outlet, Isolated		BLK	IBMA
926.038.53 Telecom Outlet, Slave 926.047.53 Twin-Telecom, Master 926.048.53 Twin-Telecom, Slave 926.040.53 Cooker Switch 45amp D/P with Neon 926.041.53 Blanking Plate Single 926.042.53 Blanking Plate Double 926.050.53 Shaver Socket BLK IBMA BLK IBMA BLK IBMA BLK IBMA BLK IBMA	926.036.53.NI	TV/FM Outlet Non-Isolated		BLK	IBMA
926.047.53 Twin-Telecom, Master 926.048.53 Twin-Telecom, Slave BLK IBMA 926.040.53 Cooker Switch 45amp D/P with Neon 926.041.53 Blanking Plate Single 926.042.53 Blanking Plate Double 926.050.53 Shaver Socket BLK IBMA BLK IBMA BLK IBMA BLK IBMA BLK IBMA BLK IBMA	926.037.53	Telecom Outlet, Master		BLK	IBMA
926.048.53 Twin-Telecom, Slave 926.040.53 Cooker Switch 45amp D/P with Neon BLK BLK IBMA 926.041.53 Blanking Plate Single IBMA 926.042.53 Blanking Plate Double IBMA 926.050.53 Shaver Socket BLK IBMA	926.038.53			BLK	IBMA
926.040.53 Cooker Switch 45amp D/P with Neon BLK BLK IBMA 926.041.53 Blanking Plate Single IBMA 926.042.53 Blanking Plate Double IBMA 926.050.53 Shaver Socket BLK IBMA	926.047.53	Twin-Telecom, Master		BLK	IBMA
926.040.53 Cooker Switch 45amp D/P with Neon BLK BLK IBMA 926.041.53 Blanking Plate Single IBMA 926.042.53 Blanking Plate Double IBMA 926.050.53 Shaver Socket BLK IBMA	926.048.53	Twin-Telecom, Slave		BLK	IBMA
926.041.53 Blanking Plate Single IBMA 926.042.53 Blanking Plate Double IBMA 926.050.53 Shaver Socket BLK IBMA		⊗			
926.042.53 Blanking Plate Double IBMA 926.050.53 Shaver Socket BLK IBMA	926.040.53		BLK	BLK	IBMA
926.050.53 Shaver Socket BLK IBMA					
	926.050.53	Shaver Socket		BLK	IBMA
	© (a) %				
926.099.53.01 I Gang Speaker Outlet BLK IBMA	926.099.53.01	I Gang Speaker Outlet		BLK	IBMA
926.234.53 I Gang Satellite Socket IBMA	926.234.53				IBMA
926.235.53 TV + Satellite Socket IBMA	926.235.53	TV + Satellite Socket			IBMA
926.236.53 TV + FM + Satellite Outlet IBMA	926.236.53	TV + FM + Satellite Outlet			IBMA
926.245.53.01 I Gang Data Socket,RJ45(Cat5) BLK IBMA	926.245.53.01	I Gang Data Socket,RJ45(Cat5)		BLK	IBMA





Small Plate

Large Plate

Interior

Material

CP

СР

СР

CP

WHI

WHI

WHI

WHI

WHI


WHI

926.061.20 926.032.20

926 Series: POLISHED CHROME

Code Description Rocker Trim	Plate			
926.061.20 I Gang Moulded Rocker Switch, 2 Way WHI 926.062.20 2 Gang Moulded Rocker Switch, 2 Way WHI	CP CP			
926.063.20 3 Gang Moulded Rocker Switch, 2 Way WHI	CP			
926.064.20 4 Gang Moulded Rocker Switch, 2 Way WHI	CP			
926.065.20 Spur Fused with Switch WHI	CP			
926.066.20 Spur Fused with Switch & Cord Outlet WHI	CP			
926.067.20 Spur Fused with Neon WHI	CP CP CP			
926.069.20 I Gang Moulded Rocker Switch: Intermediate WHI	СР			
926.070.20 Fan Isolator Switch, 3 Pole WHI	СР			
ALSO AVAILABLE LOW VOITAGE				
926.021.20 I Gang Dimmer Switch 400 Watts, 2 Way	СР			
926.022.20 2 Gang Dimmer Switch 400 Watts, 2 Way	CP CP CP CP			
926.023.20 3 Gang Dimmer Switch 400 Watts, 2 Way				
926.024.20 4 Gang Dimmer Switch 400 Watts, 2 Way				
926.026.20 I Gang Dimmer Switch 630 Watts, 2 Way				
926.027.20 2 Gang Dimmer Switch 400 Watts on Large Plate, 2Way				
926.028.20 I Gang Dimmer Switch 1000 Watts, 2 Way				

1.5mm Brass Sheet	86x86mm	I 46x86mm	MEI	М	
					·
Code Descrip	tion	Roo	ker	Trim	Plate
	• 🗎 •	9			
926.035.20 TV Outl	et, Isolated			WHI	СР
926.035.20.NI TV Outl	et, Non Isolated			WHI	CP
926.036.20 TV/FM (Outlet, Isolated			WHI	CP
926.036.20.NI TV/FM (Outlet Non-Isolated	ł		WHI	CP
926.037.20 Telecom	Outlet, Master			WHI	CP
926.038.20 Telecom	Outlet, Slave			WHI	CP
926.047.20 Twin-Te	lecom, Master			WHI	CP
926.048.20 Twin-Te	lecom, Slave			WHI	CP
	• •	© D D			



13amp Single Socket

5 amp Single Socket

13amp Double Socket


13amp Fuse-Only on 1 Gang Plate


926.030.20

926.031.20

926.032.20

926.034.20





926.032.21 926.062.21

WHI

WHI

WHI

SCP

SCP

Material	Small Plate	Large Plate	Interior
I.5mm Brass Sheet	86x86mm	146x86mm	MEM

Code Description	Rocker	Trim	Plate
926.061.21 I Gang Moulded Rocker Switch, 2 Way	WHI		SCP
926.062.21 2 Gang Moulded Rocker Switch, 2 Way	WHI		SCP
926.063.21 3 Gang Moulded Rocker Switch, 2 Way	WHI		SCP
926.064.21 4 Gang Moulded Rocker Switch, 2 Way	WHI		SCP
926.065.21 Spur Fused with Switch	WHI		SCP
926.066.21 Spur Fused with Switch & Cord Outlet	WHI		SCP
926.067.21 Spur Fused with Neon	WHI		SCP
926.069.21 I Gang Moulded Rocker Switch: Intermed	ediate WH	l	SCP
926.070.21 Fan Isolator Switch, 3 Pole	WHI		SCP
	O • (A)	ALSO AILABLE LOW Ditage	
926.021.21 I Gang Dimmer Switch 400 Watts, 2 W	ay		SCP
926.022.21 2 Gang Dimmer Switch 400 Watts, 2 W			SCP
926.023.21 3 Gang Dimmer Switch 400 Watts, 2 W			SCP
926.024.21 4 Gang Dimmer Switch 400 Watts, 2 W			SCP
926.026.21 I Gang Dimmer Switch 630 Watts, 2 W			SCP
926.027.21 2 Gang Dimmer Switch 400 Watts on La		2Way	SCP
926.028.21 I Gang Dimmer Switch 1000 Watts, 2 V	Vay		SCP
926.030.21 I3amp Fuse-Only on I Gang Plate		WHI	SCP
926.031.21 I3amp Single Socket	WHI	WHI	SCP
004,000,01	3 A /I II	VA /1 11	660

5 amp Single Socket

13amp Double Socket

926.032.21


926.034.21

926 Series: SATIN CHROME

926.035.21 TV Outlet, Isolated WHI SCP 926.035.21.NI TV Outlet, Non Isolated WHI SCP 926.036.21 TV/FM Outlet, Isolated WHI SCP 926.036.21.NI TV/FM Outlet Non-Isolated WHI SCP 926.037.21 Telecom Outlet, Master WHI SCP 926.037.21 Telecom Outlet, Slave WHI SCP 926.047.21 Twin-Telecom, Master WHI SCP 926.047.21 Twin-Telecom, Master WHI SCP 926.048.21 Twin-Telecom, Slave WHI SCP 926.048.21 Twin-Telecom, Slave WHI SCP 926.041.21 Blanking Plate Single SCP 926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP 926.050.21 Ty + Satellite Socket SCP 926.234.21 I Gang Speaker Outlet SCP 926.235.21 TV + Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.245.21.01 I Gang Data Socket,RJ45(Cat5) WHI SCP	Code	Description	Rocker	Trim	Plate
926.035.21.NI TV Outlet, Non Isolated WHI SCP 926.036.21 TV/FM Outlet, Isolated WHI SCP 926.036.21.NI TV/FM Outlet Non-Isolated WHI SCP 926.037.21 Telecom Outlet, Master WHI SCP 926.038.21 Telecom Outlet, Slave WHI SCP 926.047.21 Twin-Telecom, Master WHI SCP 926.048.21 Twin-Telecom, Slave WHI SCP 926.048.21 Twin-Telecom, Slave WHI SCP 926.041.21 Blanking Plate Single SCP 926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP 926.099.21.01 I Gang Speaker Outlet BLK SCP 926.235.21 TV + Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	· • •				
926.036.2	926.035.21	TV Outlet, Isolated		WHI	SCP
926.036.21.NI TV/FM Outlet Non-Isolated	926.035.21.NI	TV Outlet, Non Isolated		WHI	SCP
926.037.21 Telecom Outlet, Master 926.038.21 Telecom Outlet, Slave 926.047.21 Twin-Telecom, Master 926.048.21 Twin-Telecom, Slave 926.048.21 Twin-Telecom, Slave 926.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCP 926.041.21 Blanking Plate Single 926.042.21 Blanking Plate Double 926.050.21 Shaver Socket 926.050.21 Shaver Socket 926.099.21.01 I Gang Speaker Outlet 926.234.21 I Gang Satellite Socket 926.235.21 TV + Satellite Socket 926.236.21 TV + FM + Satellite Outlet SCP 926.236.21 TV + FM + Satellite Outlet SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.036.21	TV/FM Outlet, Isolated		WHI	SCP
926.038.21 Telecom Outlet, Slave 926.047.21 Twin-Telecom, Master 926.048.21 Twin-Telecom, Slave 926.048.21 Twin-Telecom, Slave 926.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCP 926.041.21 Blanking Plate Single 926.042.21 Blanking Plate Double 926.050.21 Shaver Socket 926.050.21 Shaver Socket 926.099.21.01 I Gang Speaker Outlet 926.234.21 I Gang Satellite Socket 926.235.21 TV + Satellite Socket 926.236.21 TV + FM + Satellite Outlet SCP 926.236.21 TV + FM + Satellite Outlet SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.036.21.NI	TV/FM Outlet Non-Isolated		WHI	SCP
926.047.2	926.037.21	Telecom Outlet, Master		WHI	SCP
926.048.21 Twin-Telecom, Slave WHI SCP 926.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCP 926.041.21 Blanking Plate Single SCP 926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP 926.099.21.01 I Gang Speaker Outlet BLK SCP 926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.038.21	Telecom Outlet, Slave		WHI	SCP
926.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCP 926.041.21 Blanking Plate Single SCP 926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP 926.099.21.01 I Gang Speaker Outlet BLK SCP 926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.047.21	Twin-Telecom, Master		WHI	SCP
926.040.21 Cooker Switch 45amp D/P with Neon WHI WHI SCP 926.041.21 Blanking Plate Single SCP 926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP 926.099.21.01 I Gang Speaker Outlet BLK SCP 926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.048.21	Twin-Telecom, Slave		WHI	SCP
926.041.21 Blanking Plate Single SCP 926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP		© 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0			
926.042.21 Blanking Plate Double SCP 926.050.21 Shaver Socket WHI SCP 926.099.21.01 I Gang Speaker Outlet BLK SCP 926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP			WHI	WHI	
926.050.21 Shaver Socket WHI SCP 926.099.21.01 I Gang Speaker Outlet BLK SCP 926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP		0 0			
926.099.21.01 Gang Speaker Outlet BLK SCP 926.234.21 Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP					
926.099.21.01 I Gang Speaker Outlet BLK SCP 926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.050.21	Shaver Socket		WHI	SCP
926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	· • ·		9		
926.234.21 I Gang Satellite Socket SCP 926.235.21 TV + Satellite Socket SCP 926.236.21 TV + FM + Satellite Outlet SCP	926.099.21.01	I Gang Speaker Outlet		BLK	SCP
926.236.21 TV + FM + Satellite Outlet SCP	926.234.21				SCP
	926.235.21	TV + Satellite Socket			SCP
926.245.21.01 I Gang Data Socket, RJ45(Cat5) WHI SCP	926.236.21	TV + FM + Satellite Outlet			SCP
	926.245.21.01	I Gang Data Socket,RJ45(Cat5)		WHI	SCP

SPECIAL FINISHES - Available to order








SPECIAL FINISHES - Available to order

906 Series in Antique Brass



906.001.03

906.015.07

906.092.03

906 Series in Patine (Steel Plates)





906 Series in Polished / Satin Nickel



906.002.40 Polished Nickel / White



906.091.41 Satin Nickel / White



906.071.43 Satin Nickel / Black

SPECIAL FINISHES - Available to order







Material	Small Plate	Large Plate	Interior
3mm Acrylic	86 x 86mm	146 x 86mm	Wandsworth

937 Series: 3mm FROSTED ACRYLIC PLATE



- •All Rocker Switches are available with White, Polished Brass or Satin Nickel Rocker.
- •All Dolly Switches and Dimmer Switches are available with Polished Brass or Satin Nickel Interiors.
- •All Sockets, etc are available with White Interiors. (Black on Request)

Material	Small Plate	Large Plate	Interior
3mm Acrylic	86 x 86mm	146 x 86mm	Wandsworth

938 Series: 3mm CLEAR ACRYLIC PLATE



- •All Rocker Switches are available with White, Polished Brass or Satin Nickel Rocker.
- •All Dolly Switches and Dimmer Switches are available with Polished Brass or Satin Nickel Interiors.
- •All Sockets, etc are available with White Interiors. (Black on Request)

Material	Small Plate	Large Plate	Interior
I.6mm Metal	86 x 86mm	146 x 86mm	Wandsworth


939 Series: I.6mm METAL PAINTED PLATE



 $\hbox{\bf \bullet All Sockets, etc are supplied Etch-primed in white, with White Interiors.} \\$



DECORATIVE METAL GRILLES CATALOGUE



A SELECTION OF JADO BATHROOM ACCESSORIES & MIXER TAPS



FOR FURTHER INFORMATION OR ADVICE ON DECORATIVE GRILLES, ARCHITECTURAL IRONMONGERY, BATHROOM ACCESSORIES AND TAPS, PLEASE CONTACT OUR SALES OFFICE ON TEL: 020 7483 4477 FAX: 020 7722 7992

A SELECTION FROM THE HUGE RANGE WITHIN THE ARCHITECTURAL IRONMONGERY CATALOGUE

















CENTRE DOOR KNOBS, LETTERPLATES, DOOR KNOCKERS, NUMERALS, CUPBOARD KNOBS & HANDLES, HOOKS, SHELF BRACKETS, WINDOW HARDWARE, DOOR STOPS, HINGES, BOLTS, LEVER HANDLES, ESCUTCHEONS, KNOB FURNITURE, FINGER-PLATES, CABINET LOCKS, WINDOW LOCKS, MORTISE LOCKS, RIM LOCKS.......

